

Program Control Assignments

ID	Name		
1	Concert Piano 1	MIDI 25	(Aux) Hall Level+Time
		MIDI 29	Soundboard Wet/Dry
			Soft Pedal is active
2	Stereo Solo Pno	Data	InEQ: Treb
		MIDI 25	(Aux) Hall Level+Time
		MIDI 29	Soundboard Wet/Dry
			Soft Pedal is active
3	Brt Concert Pno	Data	InEQ: Treb
		MIDI 25	(Aux) Hall Level+Time
		MIDI 29	Soundboard Wet/Dry
			Soft Pedal is active
4	Rok Piano	MIDI 25	Room Wet/Dry
		MIDI 26	(Aux) Hall Level
		MIDI 27	Hall Time
5	Piano for Lyrs	MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Time
		MIDI 29	Soundboard Wet/Dry
6	DrkPno^ArakisPno	MWheel	Vibrato (ArakisPno)
		Data	Toggle: DrkPno ^ ArakisPno
		MIDI 22	detune
		MIDI 25	(Aux) Chorus/Plate Level + Wet/Dry
		MIDI 26	Plate Time
		MIDI 27	Chorus FB
		MIDI 28	Chorus Mix
7	Honky-Tonk	MPress	Vibrato (ArakisPno)
		MWheel	Tremolo
		MIDI 25	(Aux) Hall Time
		MIDI 26	(Aux) Chorus Mix
		MIDI 27	Chorus FB
		MIDI 28	(Aux) Delay Mix
		MIDI 29	Delay Time adj
8	Pno&Syn/AcString	MWheel	String Balance
		Data	String Balance
		MIDI 22	Toggle: SynStrings/AcStrings
		MIDI 25	"(Aux) Hall Level, Room Wet/Dry(Layer 1 pno)"
		MIDI 26	Room Time
		MIDI 27	"EQ Treb boost, SRS Space"
		MIDI 28	"(Aux) Hall, Room HFDamp"
9	ClassicPiano&Vox	MWheel	Vox Level
		Data	"Vox Balance, Piano Treb boost"
		MIDI 22	Vox EQ Bass
		MIDI 23	"Vox EQ Treb, St Image Mix"
		MIDI 25	"(Aux) Hall Level, Room Wet/Dry"
		MIDI 26	Room and Hall Times
		MIDI 27	St Image In Gain
10	E Grand Stack	MIDI 28	St Image CenterGain
		MIDI 29	Vox St Image L/R Delay
		MWheel	String Level
		Data	InEQ: Treb boost
		MIDI 25	"(Aux) Room Level, (Aux) FDR Wet/Dry"
		MIDI 26	Flange Mix
		MIDI 27	Flange Tempo
		MIDI 28	Enhc Lo/Mid Drive
		MIDI 29	FDR Delay Mix adj

ID	Name		
11	Piano D'Biggy	MWheel	Vibrato
		Data	"BandPass adj, EnvCtl: Rel"
		MIDI 22	(Aux) Chorus Mix
		MIDI 23	(Aux) Delay Mix
		MIDI 24	Delay FB
		MIDI 25	(Aux) Hall Mix
		MIDI 26	Hall dry Mix+Time
		MIDI 27	InEQ: Treb
		MIDI 28	InEQ: Bass
		MIDI 29	Chorus Pitch Env adj
12	DynEPiano^EPnoPF	MWheel	Tremolo/ Vibrato
		Data	"Toggle: DynEPiano ^ EPnoPF, Chorus LFODepth+Rate, (Aux) Plate Level cut+PreDelay adj"
		MIDI 22	Chorus Wet/Dry
		MIDI 23	Chorus LFODepth
		MIDI 24	Chorus Xcouple
		MIDI 25	(Aux) Plate Wet/Dry+Decay Time
		MIDI 26	Plate Room Size
		MIDI 27	Chorus FB
		MIDI 28	Chorus Tap Level
		MIDI 29	Chorus Rate adj
13	FM-ish E-Piano	MWheel	"Layer detune, Vibrato, Saw+Shp detune"
		Data	Layer Enable
		MIDI 22	Layer detune
		MIDI 23	Layer octave shift
		MIDI 24	"Layer detune, Saw+Shp detune"
		MIDI 25	"CDR Wet/Dry, (Aux) Hall Wet/Dry+Time"
		MIDI 26	"Enhc Xover, Chorus Wet/Dry"
		MIDI 27	Chorus FB and Rate
		MIDI 28	CDR Chorus Depth
14	Suitcase E Piano	MWheel	Tremelo Depth
		Data	Tremelo Rate
		MIDI 25	(Aux) Room Level
		MIDI 26	Enhc Level
		MIDI 27	Flange Wet/Dry
		MIDI 28	"Enhc Hi Drive, Flange FB"
		MIDI 29	"Toggle: Enhc + Flange, EQ: Treb"
		BreathCtl	LoPass Freq and Res
		MWheel	Tremolo ^ Filt and Res Depth
		Data	Toggle: PhunkEPno ^ FonkMW
15	PhunkEPno^FonkMW	MIDI 22	Notch Filt Freq ^ Tremolo
		MIDI 23	"InEQ: Treb boost, Lowpass Depth ^ Tremelo Rate"
		MIDI 24	"Chrous Level, Notch Width ^ EnvCtl"
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Time
		MIDI 27	4Tapap Wet/Dry
		MIDI 28	4Tapap FB
		MIDI 29	4Tapap I/O

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
16	Clavinators 1^2	MWheel	detune/ LFO
		Data	"Toggle: Clavinators1 ^ 2 , EnvCtl: Att+Dec (Layer 8)"
		MIDI 22	"Layer Enable, Band/Lo/HiPass adj, Shaper amt"
		MIDI 23	EnvCtl: Att+Dec
		MIDI 24	"EnvCtl: Rel, (Aux) Hall Time"
		MIDI 25	Chorus FB
		MIDI 26	Chorus Rate+Depth
		MIDI 27	Delay Mix
		MIDI 28	Delay Time
		MIDI 29	Toggle: Room I/O
17	Spaceychord 1^2	MWheel	"Vibrato, Phaser LFO/Ctr Freq"
		Data	Toggle: Spaceychord 1 ^ 2
		MIDI 22	"SP4Tap Wet/Dry, Bass Freq+Res+boost"
		MIDI 23	"4Tap FB, BandPass Freq adj"
		MIDI 24	"4Tap Tempo, EnvCtl: Rel"
		MIDI 25	ChorDelay Wet/Dry
		MIDI 26	(Aux) Phase Notch
		MIDI 27	Phase FB
		MIDI 28	4Tap FB Image
		MIDI 29	Phase Level adj
18	DaNU Clavs 1^2^3	MWheel	Layer balance
		Data	Toggle: DaNU Clavs 1 ^ 2 ^ 3
		MIDI 22	Flange Wet/Dry
		MIDI 23	Flange LFO Level
		MIDI 24	EnvCtl: Att+Rel
		MIDI 25	(Aux) Chorus Slapback Level
		MIDI 26	Chorus Mix
		MIDI 27	"Flange Tempo, FB"
		MIDI 29	"Toggle: Dist/ Flange, Layer balance"
19	VAST B3! SW2+CC2	MWheel	Drawbar 9
		Data	Drawbar 1
		MIDI 22	Drawbar 2
		MIDI 23	Drawbar 3
		MIDI 24	"Drawbar 4, EnvCtl: Imp"
		MIDI 25	Drawbar 5
		MIDI 26	Drawbar 6
		MIDI 27	Drawbar 7
		MIDI 28	EnvCtl: Imp
		MIDI 29	Toggle: Vib/Chorus I/O
20	Rock Organ	Breath	"(Aux) Plate Level, Dist Drive+adj, EQ Bass+Treb"
		PWheel	Leslie Depth
		MWheel	Leslie Depth
		Data	Drawbar 1
		MIDI 22	Drawbar 2
		MIDI 23	"Drawbar 3, "
		MIDI 24	"Drawbar 4, (Aux) Plate Time"
		MIDI 25	KeyClick
		MIDI 26	Perc Harmonic (Hi/Low)
		MIDI 27	"HFDamp, Perc Decay"
		MIDI 28	Plate Level
		MIDI 29	Toggle: VibeChorus I/O

ID	Name		
21	Ballad Organ	MWheel	Leslie Depth
		Data	Drawbar 1
		MIDI 22	Drawbar 2
		MIDI 23	"Drawbar 3, (Aux) Plate Level"
		MIDI 24	"Drawbar 4, Plate Time"
		MIDI 25	KeyClick
		MIDI 26	Perc Harmonic (Hi/Low)
		MIDI 27	"HFDamp, Perc Decay"
		MIDI 28	Cabinet Dist Drive+Lopass
		MIDI 29	Toggle: VibeChorus I/O
22	Gospel Organ	MWheel	Leslie Depth
		Data	Drawbar 1
		MIDI 22	Drawbar 2
		MIDI 23	"Drawbar 3, (Aux) Plate Level"
		MIDI 24	"Drawbar 4, Plate Time"
		MIDI 25	KeyClick
		MIDI 26	Perc Harmonic (Hi/Low)
		MIDI 27	"HFDamp, Perc Decay"
		MIDI 28	Cabinet Dist Drive + Lopass adj
		MIDI 29	Toggle: VibeChorus I/O
23	OverDrive Organ	MWheel	Leslie Depth
		Data	Drawbar 1
		MIDI 22	Drawbar 2
		MIDI 23	"Drawbar 3, (Aux) Plate Level"
		MIDI 24	"Drawbar 4, Plate Time"
		MIDI 25	KeyClick
		MIDI 26	Perc Harmonic (Hi/Low)
		MIDI 27	"HFDamp, Perc Decay"
		MIDI 28	Cabinet Dist Drive+Lopass adj
		MIDI 29	Toggle: VibeChorus I/O
24	Perc Organ	MWheel	Leslie Depth
		Data	Drawbar 1
		MIDI 22	Drawbar 2
		MIDI 23	"Drawbar 3, (Aux) Plate Level"
		MIDI 24	"Drawbar 4, Plate Time"
		MIDI 25	KeyClick
		MIDI 26	Perc Harmonic (Hi/Low)
		MIDI 27	"HFDamp, Perc Decay"
		MIDI 28	Cabinet Dist Drive+Lopass adj
		MIDI 29	Toggle: VibeChorus I/O
25	Chiffy Pipes	MWheel	Decrescendo
		Data	LoPass Freq
		MIDI 22	Key Click
		MIDI 23	Vibrato
		MIDI 25	(Aux) Hall Level+Wet/Dry
		MIDI 26	Hall Time
		MIDI 27	Hall Early Ref Level
		MIDI 29	"Toggle: Chorus I/O, Hall HFDamp+PreDelay"
		MPress	Vibrato
26	Offertory	MWheel	Layer Balance
		Data	LoPass Freq
		MIDI 22	Layer Balance
		MIDI 23	InEQ: Treb boost
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Wet/Dry
		MIDI 27	Hall Time
		MIDI 28	Hall EarlyRefLevel
		MIDI 29	"Chorus I/O, EQ Mid"

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
27	Pedal Pipes	MWheel	"DecRescendo, Slight Vibrato"
		Data	Layer Balance
		MIDI 25	(Aux) Hall Level+Wet/Dry
		MIDI 26	Hall Time
		MIDI 27	Hall EarlyRefLevel
		MIDI 28	Chorus FB
		MIDI 29	"Chorus I/O, Hall adj"
28	Church Organ	MWheel	Vibrato
		Data	Layer 1 Xfade
		MIDI 22	Layer Balance
		MIDI 23	Layer Balance
		MIDI 25	(Aux) Hall Wet/Dry
		MIDI 26	Hall Time
		MIDI 27	Hall EarlyRefLevel
		MIDI 29	Toggle: Hall Mix
		MPress	Vibrato
29	DualBass^SlpBass	MWheel	Vibrato
		Data	Toggle: DualBass + SlpBass
			"EnvCtl: Dec, BandPass adj, ParaTreb"
		MIDI 22	EnvCtl: Att+Imp
		MIDI 23	EnvCtl: Rel
		MIDI 24	(Aux) Room Level+Time
		MIDI 25	Phaser Notch/ BP ^ Enhc LoDrive+Delay
		MIDI 26	Phaser Center Freq L ^ Enhc Hi Mix
		MIDI 27	Phaser Center Freq R ^ Enhc Mid Mix
		MIDI 28	Phaser FB boost * Enhc Crossover Freq
30	Warm Bases	MWheel	Vibrato
		Data	Toggle: Layers
			"LoPass adj, Shaper amt, EnvCtl: Imp+Att"
		MIDI 22	"EnvCtl: Imp, ParaBass+HighPass Freq"
		MIDI 23	"EnvCtl: Rel, InEQ: Bass"
		MIDI 24	(Aux) Room Level
		MIDI 25	Room Absorption
		MIDI 26	Comp Ratio
		MIDI 27	Comp: Att+Rel Time
		MIDI 28	add EQ Morph
31	SustBass^MixBass	MWheel	Vibrato
		Data	Toggle: SustBass + MixBass
			"BandPass Freq+Width, EnvCtl: Imp, LoPass adj"
		MIDI 22	EnvCtl: Rel
		MIDI 23	In EQ: Bass
		MIDI 24	Comp Att Time
		MIDI 25	Comp Rel Time
		MIDI 26	Comp Ratio
		MIDI 27	Comp ThReshold
		MIDI 28	"Toggle: Comp I/O, (Aux) Room I/O"
32	RickenBass	MWheel	Vibrato
		Data	Layer Enable
		MIDI 22	Bass Cut
		MIDI 23	EnvCtl: Att+Dec
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level
		MIDI 26	"Flange Wet/Dry, Chorus Wet/Dry"
		MIDI 27	"Flange FB+Level, Chorus FB"
		MIDI 28	"Flange L/R phase, Chorus Rate"
		MIDI 29	Toggle: Flange + Chorus
33	Synth Fretless	MWheel	Vibrato
		Data	Toggle: Shaper amt, HiPass Freq"
		MIDI 22	InEQ: Bass
		MIDI 23	EnvCtl: Imp
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level
		MIDI 26	"Flange Wet/Dry, Chorus Wet/Dry"
		MIDI 27	"Flange FB, Chorus FB"
		MIDI 28	"Flange L/R Phase, Chorus Rate"
		MIDI 29	Toggle: Flange + Chorus
34	Moogy Bass 1^2	MWheel	Vibrato
		Data	Toggle: Moogy Bass 1 ^ 2
		MIDI 22	"LoPass Filt adj, EnvCtl: Att"
		MIDI 23	EnvCtl: Imp
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Place Level
		MIDI 26	"Flange Wet/Dry(sys), Stlmg EQ Bass"
		MIDI 27	"Flange FB, Stlmg CenterGain"
		MIDI 28	"Place HFDamp, Flange HFDamp, Stlmg L/R Delay"
		MIDI 29	Toggle: Flange + Widespread (Stlmg)
35	Moogy Bass 3^4	MWheel	Vibrato
		Data	Toggle: Moogy Bass 3 ^ 4
		MIDI 22	"LoPass Freq, EnvCtl: Imp"
		MIDI 23	LoPass Res
		MIDI 24	EnvCtl: Imp+Rel
		MIDI 25	"(Aux) Chorus Level+Wet/Dry, (fx2) Room Cut"
		MIDI 26	"(fx2)Chorus Mix, Enhc Crossover 1"
		MIDI 27	"Chorus FB, Enhc Crossover 2"
		MIDI 28	"Room HFDamp, Enhc Drive adj"
		MIDI 29	Toggle: ChorVerb + Enhc; Enhc Lo+Mid+Hi Drive

ID	Name		
27	Pedal Pipes	MWheel	"DecRescendo, Slight Vibrato"
		Data	Layer Balance
		MIDI 25	(Aux) Hall Level+Wet/Dry
		MIDI 26	Hall Time
		MIDI 27	Hall EarlyRefLevel
		MIDI 28	Chorus FB
		MIDI 29	"Chorus I/O, Hall adj"
28	Church Organ	MWheel	Vibrato
		Data	Layer 1 Xfade
		MIDI 22	Layer Balance
		MIDI 23	Layer Balance
		MIDI 25	(Aux) Hall Wet/Dry
		MIDI 26	Hall Time
		MIDI 27	Hall EarlyRefLevel
		MIDI 29	Toggle: Hall Mix
		MPress	Vibrato
29	DualBass^SlpBass	MWheel	Vibrato
		Data	Toggle: DualBass + SlpBass
			"EnvCtl: Dec, BandPass adj, ParaTreb"
		MIDI 22	EnvCtl: Att+Imp
		MIDI 23	EnvCtl: Rel
		MIDI 24	(Aux) Room Level+Time
		MIDI 25	Phaser Notch/ BP ^ Enhc LoDrive+Delay
		MIDI 26	Phaser Center Freq L ^ Enhc Hi Mix
		MIDI 27	Phaser Center Freq R ^ Enhc Mid Mix
		MIDI 28	Phaser FB boost * Enhc Crossover Freq
30	Warm Bases	MWheel	Vibrato
		Data	Toggle: Layers
			"LoPass adj, Shaper amt, EnvCtl: Imp+Att"
		MIDI 22	"EnvCtl: Imp, ParaBass+HighPass Freq"
		MIDI 23	"EnvCtl: Rel, InEQ: Bass"
		MIDI 24	(Aux) Room Level
		MIDI 25	Room Absorption
		MIDI 26	Comp Ratio
		MIDI 27	Comp: Att+Rel Time
		MIDI 28	add EQ Morph
31	SustBass^MixBass	MWheel	Vibrato
		Data	Toggle: SustBass + MixBass
			"BandPass Freq+Width, EnvCtl: Imp, LoPass adj"
		MIDI 22	EnvCtl: Rel
		MIDI 23	In EQ: Bass
		MIDI 24	Comp Att Time
		MIDI 25	Comp Rel Time
		MIDI 26	Comp Ratio
		MIDI 27	Comp ThReshold
		MIDI 28	"Toggle: Comp I/O, (Aux) Room I/O"
32	RickenBass	MWheel	Vibrato
		Data	Layer Enable
		MIDI 22	Bass Cut
		MIDI 23	EnvCtl: Att+Dec
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level
		MIDI 26	"Flange Wet/Dry, Chorus Wet/Dry"
		MIDI 27	"Flange FB+Level, Chorus FB"
		MIDI 28	"Flange L/R phase, Chorus Rate"
		MIDI 29	Toggle: Flange + Chorus
33	Synth Fretless	MWheel	Vibrato
		Data	Toggle: Shaper amt, HiPass Freq"
		MIDI 22	InEQ: Bass
		MIDI 23	EnvCtl: Imp
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level
		MIDI 26	"Flange Wet/Dry, Chorus Wet/Dry"
		MIDI 27	"Flange FB, Chorus FB"
		MIDI 28	"Flange L/R Phase, Chorus Rate"
		MIDI 29	Toggle: Flange + Chorus
34	Moogy Bass 1^2	MWheel	Vibrato
		Data	Toggle: Moogy Bass 1 ^ 2
		MIDI 22	"LoPass Filt adj, EnvCtl: Att"
		MIDI 23	EnvCtl: Imp
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Place Level
		MIDI 26	"Flange Wet/Dry(sys), Stlmg EQ Bass"
		MIDI 27	"Flange FB, Stlmg CenterGain"
		MIDI 28	"Place HFDamp, Flange HFDamp, Stlmg L/R Delay"
		MIDI 29	Toggle: Flange + Widespread (Stlmg)
35	Moogy Bass 3^4	MWheel	Vibrato
		Data	Toggle: Moogy Bass 3 ^ 4
		MIDI 22	"LoPass Freq, EnvCtl: Imp"
		MIDI 23	LoPass Res
		MIDI 24	EnvCtl: Imp+Rel
		MIDI 25	"(Aux) Chorus Level+Wet/Dry, (fx2) Room Cut"
		MIDI 26	"(fx2)Chorus Mix, Enhc Crossover 1"
		MIDI 27	"Chorus FB, Enhc Crossover 2"
		MIDI 28	"Room HFDamp, Enhc Drive adj"
		MIDI 29	Toggle: ChorVerb + Enhc; Enhc Lo+Mid+Hi Drive

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
36	Matrix Big Bass	MWheel	Vibrato
		Data	Layer Toggle
		MIDI 22	"EnvCtl: Imp+Att, LoPass adj"
		MIDI 23	EnvCtl: Dec
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Room Level+HFDamp
		MIDI 26	"Flange Wet/Dry, Tube Drv"
		MIDI 27	"Flange LFO period, MDelay Wet/Dry"
		MIDI 28	"Flange FB, MDelay FB, Dist Warmth"
		MIDI 29	Toggle: Flange + TubeAmpDelayCh
		MPress	Vibrato
37	Pitt Bass mono 1^2	MWheel	Vibrato
		Data	"Layer Enable, EnvCtl: Rel"
		MIDI 22	"PWM Filt+Width adj, EnvCtl: Att+Dec, ParaBass Frq"
		MIDI 23	"InEQ: Bass, EnvCtl: Imp"
		MIDI 24	"InEQ: Treb, EnvCtl: Rel"
		MIDI 25	(Aux) Chamber Mix
		MIDI 26	Chamber HFDamp+Time
		MIDI 27	Chorus FB
		MIDI 28	Delay Mix
		MIDI 29	Chorus Depth
		MPress	Vibrato
38	Punch Bass 1^2	MWheel	"Vibrato, LoPass Res"
		Data	Toggle: Punch Bass 1 ^ 2
		MIDI 22	InEQ: Bass
		MIDI 23	EnvCtl: Imp+Att
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Chamber Mix+Level+Time+HFDamp
		MIDI 26	InEQ: Treb
		MIDI 27	Chorus FB
		MIDI 28	Chorus Depth
		MIDI 29	Flange I/O
		MPress	Vibrato
39	Tee Bee This MW	MWheel	LoPass Freq
		Data	LoPass Res
		MIDI 22	EnvCtl: Imp
		MIDI 23	EnvCtl: Att
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level+adj
		MIDI 26	Chorus Wet/Dry
		MIDI 27	Chorus FB
		MIDI 28	Chorus Tap Pan
		MIDI 29	add Enhc
		MPress	Vibrato
40	BottomFeed^Pulse	MWheel	Vibrato
		Data	Toggle: BottomFeed ^ Pulse
		MIDI 22	"LoPass Gate+Freq, EnvCtl: Imp+Att"
		MIDI 23	"EnvCtl: Att+Dec, Saw Pitch adj"
		MIDI 24	EnvCtl: Rel
		MIDI 25	"(Aux) Room Level, (FX3)Hall Mix"
		MIDI 26	Chorus Mix
		MIDI 27	Chorus Rate
		MIDI 28	Chorus FB
		MIDI 29	Toggle: Chorus(4Tap) + Flange
		MPress	Vibrato

ID	Name		
41	SkoolBass^Simple	MWheel	Vibrato
		Data	Toggle: SkoolBass ^ Simple
		MIDI 22	"Pulse Width+Freq, Pitch adj, EnvCtl: Imp+Att"
		MIDI 23	"Dist Drive adj, EnvCtl: Dec"
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Room Level
		MIDI 26	"Phase Notch/ Dry, Dist Wet/Dry"
		MIDI 27	"Phase Center Freq, Dist Drive adj"
		MIDI 28	"Phase LFO Depth, Dist Bass adj"
		MIDI 29	"Toggle: Phase + Dist, Room Time adj"
		MPress	Vibrato
		AttVel	LoPass gate
42	MonoBass^FixBass	GKeyNum	L/R Phase
		MW	Vibrato
		Data	"Toggle: MonoBass ^ FixBass, BandPass Width"
		MIDI 22	"LoPass Freq, ^ Notch Freq+Width, EnvCtl: Imp"
		MIDI 23	"InEQ: Bass, EnvCtl: Att"
		MIDI 24	"InEQ: Treb, Hall HFDamp, EnvCtl: Rel"
		MIDI 25	(Aux) CDR Level+Hall Time
		MIDI 26	Delay Mix
		MIDI 27	Phaser FB Cut
		MIDI 28	"Phaser LFO Rate, Hall Mix"
		MIDI 29	"Chorus-Delay Cut, Phase Notch adj"
		MPress	Vibrato
43	Ravelike Bass	MWheel	Vibrato
		Data	Later Enable
		MIDI 22	"LoPass Res, EnvCtl: Att"
		MIDI 23	"InEQ: Bass, EnvCtl: Imp"
		MIDI 24	"InEQ: Treb, EnvCtl: Dec+Rel"
		MIDI 25	(Aux) Room Level
		MIDI 26	Flange Mix (sys)
		MIDI 27	"Pitcher Mix, LsrDelay HFDamp"
		MIDI 28	"Pitcher Pitch, LsrDelay Time"
		MIDI 29	Toggle: Laserverb I/O
		MPress	Vibrato
44	Junosis^Geo-Bass	MWheel	Oscillator Vibrato
		Data	"LoPass Freq, Layer Enable"
		MIDI 22	LoPass Res
		MIDI 23	"Pitch Env, EnvCtl: Rel"
		MIDI 24	EnvCtl: Imp
		MIDI 25	EnvFilt Wet/Dry
		MIDI 26	EnvFilt Min Freq
		MIDI 27	InEQ: Bass
		MIDI 28	InEQ: Treb
		MIDI 29	Toggle: (Aux) SweepFilt I/O
		MPress	Sweep Res
		PWheel	(+/-) 2 octaves

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
45	Ace Bass^ChirpBas	MWheel	Vibrato
		Data	"Toggle: Ace Bass ^ Chirp Bass, LoPass Filt+Res"
		MIDI 22	"HiPass Freq, LoPass Res, EnvCtl: Imp"
		MIDI 23	"LoPass Res, EnvCtl: Att"
		MIDI 24	EnvCtl: Att+Rel
		MIDI 25	(Aux) Room Level
		MIDI 26	"Flange Wet/Dry, Chorus Wet/Dry"
		MIDI 27	"Flange FB, Chorus FB"
		MIDI 28	"Flange LFO Period, Chorus Tap Delay"
		MIDI 29	Toggle: Flange + Chorus
		MPress	Vibrato
		PW	Octave Shift
46	Gritz	MWheel	Vibrato + Shaper Pitch Cut
		Data	LoPass Freq
		MIDI 22	LoPass Res
		MIDI 23	"Pitch ASR, EnvCtl: Imp"
		MIDI 24	EnvCtl: Release
		MIDI 25	"(Aux) Room Level, Laser FB"
		MIDI 26	"LsrDelay Time, TubeDrive adj"
		MIDI 27	"LsrDelay Spacing, Tube Warmth"
		MIDI 28	LsrDelay Contour
		MIDI 29	Toggle: LaserDelay + TubeDrive
		MPress	Vibrato
47	Homey Saw	MWheel	Vibrato
		Data	Pitch
		MIDI 22	"LoPass Res, Freq, Chorus Cut, EnvCtl: Imp"
		MIDI 23	"InEQ: Bass, EnvCtl: Att+Dec"
		MIDI 24	"InEQ: Treb, EnvCtl: Rel"
		MIDI 25	(Aux) Hall Level
		MIDI 26	Chorus FB
		MIDI 27	Delay Mix
		MIDI 28	Delay Time
		MIDI 29	Hall Decay Time+Room size
		MPress	Vibrato
48	OG	MWheel	Sync Amp (AClock)
		Data	Sync M Pitch
		MIDI 22	Sync S Pitch
		MIDI 23	EnvCtl: Att
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Plate Level
		MIDI 26	Plate Time+HFDamp
		MIDI 27	Tube Drive
		MIDI 28	MDelay Wet/Dry
		MIDI 29	TubeDelayCh Wet/Dry
49	Lowdown Bass	MWheel	"Vibrato, HiPass Freq (Chirp)"
		Data	LoPass Gate
		MIDI 22	EnvCtl: Imp
		MIDI 23	EnvCtl: Att
		MIDI 24	"Layer Enable, EnvCtl: Dec+Rel"
		MIDI 25	(Aux) Dist Level
		MIDI 26	"Dist Drive, Mid EQ cut, Flange Wet/Dry"
		MIDI 27	"InEQ: Bass, Flange FB"
		MIDI 28	Cab HiPass
		MIDI 29	Toggle: EQ + Flange
		MPress	Vibrato

ID	Name		
50	SquashStudio Kit	MWheel	AltControl: Toms
		Data	"Pitch: Kicks, Snares, Toms, HiHats"
		MIDI 22	Snare Filters
		MIDI 23	Kick Filters
		MIDI 24	"EnvCtl: Kicks, Snares, Toms"
		MIDI 25	"(FX1+2)- (Aux) Room Level+Time, (FX2)- Mix Level "
		MIDI 26	(FX2) Compressor Ratio+Gain
		MIDI 27	Room HFDamp
		MIDI 28	"Toggle: Enhancer HiDrive, Room PreDelay"
		MIDI 29	Enhancer Hi Delay Time
51	Retro Skins MW	MWheel	Multiple Layer Toggle
		Data	Pitch: Kicks
		MIDI 22	Pitch: Snares
		MIDI 23	"Filter Freq: Kicks, Toms, Ride, AuxPerc "
		MIDI 24	EnvCtl: Kicks+Snares
		MIDI 25	(FX1+2) Rooms Wet/Dry
		MIDI 26	(Aux) Room Wet/Dry
		MIDI 27	(Aux) Compressor Attack Time
		MIDI 28	(FX1) InEQ: Bass+Treb
		MIDI 29	Toggle: Alien Skin Effect
52	2 Live Kits 2 MW	MWheel	Multiple Layer Toggle
		Data	"Pitch: Kicks, Toms"
		MIDI 22	Pitch: Snares
		MIDI 23	"HF Stimulator: Cymbal, HiHats"
		MIDI 24	"EnvCtl: Kicks, Snares, Toms, Cymbal"
		MIDI 25	"(FX1)-(Aux) Hall Level, (FX2) Plate PreDelay"
		MIDI 26	(FX2)-(Aux) Hall Level
		MIDI 27	(FX1) GateRvb Wet/Dry+Gate Threshold
		MIDI 28	"Hall Time, Plate Wet/Dry"
		MIDI 29	Toggle: Plate RvbTime boost-Megaverb!
53	Garage Kit II MW	MWheel	Multiple Layer Toggle
		Data	"Pitch: Kicks, Toms"
		MIDI 22	"Pitch: Snares, Crash2"
		MIDI 23	"EnvCtl: Kicks, Toms"
		MIDI 24	"EnvCtl: Snares, HiHats"
		MIDI 25	(Aux) RoomGate Absorption+Gain
		MIDI 26	(FX3) Compression control
		MIDI 27	(FX3) InEQ: Treb
		MIDI 28	(FX3) InEQ: Bass
		MIDI 29	"Toggle: (Aux) Room type, Lopass adj"
54	Jazz Kit II	MWheel	Pitch: AuxPerc
		Data	"Pitch: Kicks, Toms"
		MIDI 22	Pitch: Snares
		MIDI 23	"Gain: HiHats, Crash Cym"
		MIDI 24	"EnvCtl: Kicks, Toms"
		MIDI 25	(FX1+2) Rooms Wet/Dry+Time
		MIDI 26	"(FX1+2)- (Aux) Hall Level, (FX2)- Mix Level"
		MIDI 27	(FX2) In EQ: Treb cut
		MIDI 28	(Aux) Hall TrebShlf Freq+cut

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
55	Hoppy Kit!	MWheel	"Notchy Filter: Toms, CrossStick"
		Data	"Pitch: Kicks, Toms, HiHats, Cowbell"
		MIDI 22	"Pitch: Snares, Crash1, Ride, Clap, Clave, Tambourine"
		MIDI 23	"Filter: Kicks, Snare2-3, Crash2, Ride; [Impact on Kick2]"
		+MW	"Filter: Snare1, HiHats, Crash1, AuxPerc"
		MIDI 24	"EnvCtl: Toms, Kick1, Snares"
		MIDI 25	"(FX1) Room Wet/Dry, (FX2) Flange Wet/Dry"
		MIDI 26	(Aux) Booth Level
		MIDI 27	Booth Absorption
		MIDI 28	"Room HFDamp, Flange FB"
		MIDI 29	Toggle: Room + Flange
56	L'il Nipper Kit	MWheel	SFX Pitch
		Data	"Pitch: Kick, Toms"
		MIDI 22	"Pitch: Snares, AuxPerc"
		MIDI 23	"Filter: Hihats, Cymbals"
		MIDI 24	"EnvCtl: Kicks, Snares"
		MIDI 25	(Aux) Plate Time
		MIDI 26	(FX3) Laserverb Spacing
		MIDI 27	"(FX2) Pitcher Pitch, Pitcher Wet/Dry"
		MIDI 28	Pitcher control
		MIDI 29	Laserverb Delay+Contour+FB
		MPress	AuxPerc Pitch
57	Geo-Kit MW+22	MWheel	Multiple Layer Toggle
		Data	"Pitch: Kicks, Snares, Toms, ""Shaker"""
		MIDI 22	Crossfade to tertiary Kicks; Pitch: Elec. Snare only
		MIDI 23	"Filter: Kicks, Snares, HiHats, Crashes, Ride, ""Shaker"";"
			Amp LFO: SFX (A6-B6)
		MIDI 24	"EnvCtl: most Kicks, Snares, Toms, ""Shaker"" , Elec HiHat"
			LFO Rate: SFX (A6-B6)
		MIDI 25	"(FX3) Mix Level, (Aux) GateRvb Level"
		MIDI 26	"(FX4) Mix Level, GateRvb Level"
		MIDI 27	(FX3) Compressor SmoothTime+MakeUpGain
		MIDI 28	"(FX2) EnvFlt Freq Sweep+Threshold, (FX1) Delay Level"
		MIDI 29	Toggle: Compressor + ChorDelay
58	Lo-Fi Vinyl Kit	MWheel	Pitch for most Needle FX and other SFX
		Data	"Pitch: Kicks, Toms, HiHats"
		MIDI 22	"Pitch: Snares, Crash1"
		MIDI 23	"Assorted Filters: Kick, Toms, Snares,"
			"HiHats, Crashes, Ride (Resonant)"
		MIDI 24	"EnvCtl: Kick, Toms, Snares"
		MIDI 25	(FX1) Booth Wet/Dry
		MIDI 26	(Aux) Hall Level
		MIDI 27	"(FX2) Pitcher Wet/Dry, (FX3) LaserVerb Wet/Dry"
		MIDI 28	"(FX2) Pitcher Pitch, (FX3) LaserVerb Delay"
		MIDI 29	Toggle: Pitcher + LaserVerb

ID	Name		
59	Technoo Kit	MWheel	Alternate Kick (B2-C3)
		Data	Pitch: nearly all elements
		MIDI 22	"Filter: Kicks, AuxPerc"
		MIDI 23	"Filter: Snares, Toms, Ride, Crashes, HiHats (A#1-B1)"
		MIDI 24	"EnvCtl: Kicks, Snares (not G#1-A1), Ride, Choke Cym"
		MIDI 25	(FX1) Gated Reverb Wet/Dry
		MIDI 26	Gated Reverb Time
		MIDI 27	(FX1+2) (Aux) LaserVerb Level
		MIDI 28	(FX4) LaserVerb Level
		MIDI 29	Toggle: GateRvb HFDamp+Gate Threshold
60	VAST Sliders 808	MWheel	"AltStart control, Impact on most elements"
		Data	"Pitch: Kicks, Toms"
		MIDI 22	"Pitch: Snares, NoizeToms"
		MIDI 23	"EnvCtl: Kicks, Toms"
		MIDI 24	"EnvCtl: Snares, HiHats, Crash2, NoizeToms"
		MIDI 25	(FX1) Hall Wet/Dry
		MIDI 26	(FX4)- (Aux) Room Level (dry at very top)
		MIDI 27	"Hall Time, Room Decay Time+HFDamp"
		MIDI 28	"(FX2) Flange Wet/Dry+FB, (FX3) 8-Tap Wet/Dry"
		MIDI 29	"Toggle: 8-Tap I/O (Sys), Room Level adj"
61	Industry Set II	MWheel	Filter Resonance (A#4-C5)
		Data	"AltControl on some layers,"
			Pitch on Kick-like elements and some Toms
		MIDI 22	Various Pitch controls on many elements
		MIDI 23	Filters or Modulation Pitch on many elements
		MIDI 24	EnvCtl: assorted kinds of control on many elements
		MIDI 25	"(FX2) Flange Wet/Dry, InEQ: Bass"
		MIDI 26	"(Aux) Hall Level, (FX2) Mix Level"
		MIDI 27	(FX3) DistEQ Wet/Dry+Gain Adjust
		MIDI 28	Distortion Warmth
		MIDI 29	Toggle: RoomType: Hall + Delay
62	General MIDI Kit	MWheel	Filter Resonance (A#4-C5)
		MPress	Filter Resonance (A#4-C5)
		MWheel	"Assorted Filters, on most elements"
		Data	"Pitch: Kicks (B1, C2), and Toms"
		MIDI 22	"Pitch: Snares (D2, E2), HiHats, Ride, Crash (C#3)"
		MIDI 23	"Pitch: Congas, Timbales, many other elements"
		MIDI 24	"EnvCtl / ASR Amp Env: Kicks (above), Snares (above)"
			"Toms, Crashes, Ride, Triangle, Ding (A#1)"
		MIDI 25	(FX1) Room Wet/Dry
		MIDI 26	Room Rvb Time
		MIDI 27	"(Aux) Hall Level, (FX1) Mix Level"
		MIDI 28	(FX1) Compressor Ratio+Threshold+Rel Time
		MIDI 29	"Toggle: (FX1) Room+Booth, (Aux) Hall+""Slither Booth"""

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
63	Slam'n Drums2 GM	MWheel	"Lowpass Filter and Filter Env Ctrl, many elements"
		Data	"Pitch: Kicks (B1, C2, D6)"
		MIDI 22	"Pitch: Snares (D2, E2), Toms, HiHats"
		MIDI 23	"Filters: Kicks and Snares (above), Toms; HiHat boost"
		MIDI 24	"EnvCtl / ASR Amp Env: Kicks, Snares, Toms"
		MIDI 25	(FX1) Gated Reverb Wet/ Dry+Time+HFDamp
		MIDI 26	(FX2) Sweep Filter Wet/Dry
		MIDI 27	(FX1) FlangeDelay Level (Sys)
		MIDI 28	(FX2) FlangeDelay Level (Sys)
		MIDI 29	Toggle: Sweep Filt direction Rise + Fall
64	EleCtroDrumsetGM	MWheel	(FX2) Resonant Filter Freq
		Data	"Filter: Kicks, Toms, assorted other elements"
		MIDI 22	"Pitch: Snares, some Toms, Cymbals,+other elements"
		MIDI 23	"Filter: Snares, Cymbals, HiHats, Synth Boing"
		MIDI 24	EnvCtl: most elements
		MIDI 25	"(FX1) Room Wet/Dry, (FX3) Echo Wet/Dry, (Aux) Hall Wet/ Dry+Level"
		MIDI 26	"Room Time, (Aux) Hall Level"
		MIDI 27	Hall Late Rvrb Time
		MIDI 28	(FX3) Delay Feedback (only a few elements)
		MIDI 29	"Toggle: Room + ResFilt, Delay + Room"
65	SmallKit+Perc MW	MWheel	Cowbell + Shaker Enable
		Data	"Pitch: Kit elements (Kick, Snare, HiHats, Toms, Cymbals)"
		MIDI 22	"Pitch: Congas, Timbales, Agogo, Clave, Cowbell (MW)"
		MIDI 23	"Filters: Cabasas, Tambourines, Clave, Agogo, "
			"Timbales, Kick, Snare, HiHats, Toms, Cowbell (MW)"
		MIDI 24	"Pitch+Filter: Cabasas, Shaker (MW), Tambourine (F#3, F#4)"
		MIDI 25	(FX1+2) Rooms Wet/Dry
		MIDI 26	Rooms' Times
		MIDI 27	"(Aux) Plate Level, (FX4) Mix Level, (FX3) Hall Wet/Dry"
		MIDI 28	Plate Time
		MIDI 29	Toggle: Room + Hall
66	Steel Str Guitar	MWheel	Vibrato
		Data	Layr Enable
		MIDI 22	EnvCtl: Imp
		MIDI 23	EnvCtl: Att+Dec
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Chamber Wet/Dry
		MIDI 26	Chamber Time
		MIDI 27	Chamber HFDamp
		MIDI 28	Comp Ratio
		MIDI 29	Toggle: Pitch I/O
		MPress	Vibrato

ID	Name		
67	12-str Guitar	MWheel	Vibrato
		Data	HFStim EQ
		MIDI 22	EnvCtl: Imp
		MIDI 23	EnvCtl: Att
		MIDI 24	EnvCtl: Rel
		MIDI 25	(FX1+2) Room Wet/Dry+(FX1) Time
		MIDI 26	(Aux) Hall Level
		MIDI 27	Hall Time
		MIDI 28	Room + Hall HFDamp
		MIDI 29	Toggle: (fx1+2) Room Reverbs
68	Spark Guitar	MPress	Vibrato
		Soft Pdl	Active
		MWheel	Vibrato
		Data	HFStim adj
		MIDI 22	EnvCtl: Imp+Att
		MIDI 23	EnvCtl: Dec
		MIDI 24	EnvCtl: Rel
		MIDI 25	"(fx1) Room Mix, (Aux) Hall Level"
		MIDI 26	Hall PreDelay+Time
		MIDI 27	Delay Mix (sys)
69	Blue Moods	MIDI 28	Chorus Delay
		MIDI 29	Chorus FB
		MPress	Vibrato
		MWheel	"Slight Vibrato, String Balance"
		Data	"String Balance, Gtr Hi Freq Cut"
		MIDI 22	EnvCtl: Imp+Att
		MIDI 23	EnvCtl: Dec
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Time+HFDamp
70	SloChrsGtr^Harms	MIDI 27	"Enhc Lo Mix, Chorus Wet/Dry"
		MIDI 28	"Enhc Hi Mix+Drive, Chorus FB"
		MIDI 29	"Toggle: Enhc + Chorus, Hall + Room"
		MPress	Vibrato
		MWheel	Tremolo
		Data	Toggle: SloChorusGuit ^ Harms
		MIDI 22	Para EQ (VAST)
		MIDI 23	"LoPass Res, Chorus (VAST) adj"
		MIDI 24	"EnvCtl: Dec+Rel, Harm(Sin) Oct Shift"
		MIDI 25	(Aux) Hall Level
		MIDI 26	"Hall Time+HFDamp, Chorus Wet/Dry"
		MIDI 27	"Enhc Lo Mix, Chorus FB"
		MIDI 28	Enhc Hi Mix+Drive
		MIDI 29	"Toggle: Enhc + Chorus, Hall + Room"
		MPress	Vibrato

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
71	ES335^Abercrombie	MWheel	Notch Filt Tremolo
		Data	Toggle: ES335 ^ Abercrombie
		MIDI 22	"Para Mid Freq, ^ Notch Freq"
		MIDI 23	"Para Mid Amp (ES335), "
		MIDI 24	"EnvCtl: Att+Rel, ^EnvCtl: Imp+Att"
		MIDI 25	(Aux) Hall Mix
		MIDI 26	"Hall HFDamp, InEQ: Bass+Treb (Abercrombie)"
		MIDI 27	Chorus Mix
		MIDI 28	Delay Mix
		MIDI 29	Turns off Semi-Tone Pitch Bend
		MPress	Vibrato
		PWheel	Simulates Fretboard Slide (ES335)
72	SliderDistJazzGt	MWheel	Vibrato/Tremolo
		Data	Enables Dist Gtr Layers
		MIDI 22	"Para EQ ^ Hi Freq Stim Drive, Dist EQ"
		MIDI 23	"EnvCtl: Imp, Dist Drive"
		MIDI 24	EnvCtl: Rel
		MIDI 25	"(Aux) FDR Hall Level, Rvb Time"
		MIDI 26	Flange FB
		MIDI 27	Flange Tempo
		MIDI 28	Delay Mix
		MIDI 29	Delay FB
		MPress	"Vibrato, Harmonics Level"
		PWheel	(Dist Layer) +2/-12 Pitch Bend
73	Crunchy Lead	MWheel	Vibrato
		Data	Layer Enable
		MIDI 22	(KDFX)Dist Drive
		MIDI 23	(KDFX)Dist Freq
		MIDI 24	EnvCtl: Dec+Rel
		MIDI 25	"(Aux) FDR Level, Hall Time"
		MIDI 26	Flange FB
		MIDI 27	Flange Tempo
		MIDI 28	Delay Mix
		MIDI 29	Delay FB
		MPress	Layer Balance
74	NooMutes^WahTaur	MWheel	Notch and Para EQ Width
		Data	Toggle: Noo Mutes ^ WahTaur
		MIDI 22	" Notch Freq (Mutes), BandPass Filt LFO Rate (Wah)"
		MIDI 23	EnvCtl: Imp
		MIDI 24	EnvCtl: Att
		MIDI 25	"(FX1) Hall Wet/Dry, (FX3) Room Mix, (Aux) Room Level"
		MIDI 26	"Delay Mix, Chorus Wet/Dry"
		MIDI 27	"Delay FB, Chorus FB"
		MIDI 28	Delay Time
		MIDI 29	Toggle: FDR + Chorus
		MPress	Vibrato
		AttVel	EnvCtl: Decay

75	CeeTaur^Kotolin	MWheel	Vibrato + EQ
		Data	Toggle: Cee Taur ^ Kotolin
		MIDI 22	EnvCtl: Imp
		MIDI 23	EnvCtl: Att
		MIDI 24	EnvCtl: Rel
		MIDI 25	"(Aux) Hall Level, (Fx3) Rvb Time"
		MIDI 26	(Fx2) Phase Wet/Dry
		MIDI 27	"Phase L/R LFO, (Fx3) Flange Mix"
		MIDI 28	Delay Mix
		MIDI 29	"Buss Toggle:, Phaser LFO Rate"
		MPress	Vibrato
76	Liquid T Lead	MWheel	Vibrato
		Data	"EnvCtl: Att, LoPass Freq+Res"
		MIDI 22	"Lopass Freq+Res, Steep Bass Freq"
		MIDI 23	EnvCtl: Imp
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level
		MIDI 26	"Hall Time+HFDamp, Chorus FB"
		MIDI 27	"Delay Mix, SRS EQ"
		MIDI 28	"Delay FB, SRS Centerspace"
		MIDI 29	Toggle: CHDelay + SRS
		MPress	"Vibrato, Layer Enable (Harmonics)"
77	Square Lead	MWheel	Vibrato
		Data	"EnvCtl: Att+Dec, LoPass Freq+Res"
		MIDI 22	LoPass Freq+Res
		MIDI 23	InEQ: Bass
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Decay+HFDamp
		MIDI 27	"Flange Wet/Dry, DistDrive adj"
		MIDI 28	"Flange FB+Xcouple+HFDamp, Dist EQ"
		MIDI 29	Toggle: DistFlange I/O
		MPress	"Vibrato, Layer Enable (Harmonics)"
78	AlaZawi Take 2	MWheel	Vibrato
		Data	LoPass Freq+Res
		MIDI 22	LoPass Freq cut
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Level+Decay Time
		MIDI 26	Hall PreDelay+HFDamp
		MIDI 27	Chorus Wet/Dry+Pan
		MIDI 28	MDelay Wet/Dry
		MIDI 29	Toggle: Clean + MDelayChorus
		Breath	LoPass Freq+Res adj
		MPress	Vibrato
79	Modulead	MWheel	"Vibrato, Harmonic Balance"
		Data	Filt Freq
		MIDI 22	LoPass Res adj
		MIDI 23	EnvCtl: Imp
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Mix
		MIDI 26	Chorus Mix
		MIDI 27	Chorus FB
		MIDI 28	"Phase Center Freq + Notch, Pan Pulse Width"
		MIDI 29	Toggle: Phaser + Panner
		MPress	"Slight Vibrato, LoPass adj"

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
80	Polyreal Mini	MWheel	Vibrato
		Data	LoPass Res
		MIDI 22	LoPass Freq
		MIDI 23	"InEQ: Bass, EnvCtl: Att"
		MIDI 24	"InEQ: Treb, EnvCtl: Rel"
		MIDI 25	(Aux) Hall Level+Wet/Dry
		MIDI 26	Hall Decay Time+HFDamp
		MIDI 27	Hall PreDelay
		MIDI 28	Chorus Delay Time+Wet/Dry
		MIDI 29	Delay Mix
		MPress	Vibrato
81	3 Modular Leads	MWheel	Vibrato
		Data	Toggle: Modular Leads
		MIDI 22	"EnvCtl: Imp, HiPass Freq"
		MIDI 23	EnvCtl: Att
		MIDI 24	EnvCtl: Rel
		MIDI 25	"(Aux) Hall Level, (FX3) Plate Mix"
		MIDI 26	Hall + Plate PreDelay
		MIDI 27	"Flange Wet/Dry, Delay Mix"
		MIDI 28	"Flange FB, Delay FB"
		MIDI 29	Toggle: Flange + CDR
82	Soul Boy Lead	MWheel	Vibrato
		Data	Filt Freq+Res
		MIDI 22	InEQ: Bass+Treb
		MIDI 23	EnvCtl: Att
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Decay+HFDamp
		MIDI 27	Chorus Mix
		MIDI 28	Delay Mix
		MIDI 29	"Toggle: Delay FB, Chorus adj"
83	Fluty Leads	MWheel	Vibrato
		Data	Pitch - Octave Shift
		MIDI 22	InEQ: Bass
		MIDI 23	InEQ: Treb
		MIDI 24	EnvCtl: Rel
		MIDI 25	"(Aux) Hall Level, (FX3) Hall Mix"
		MIDI 26	(Aux) Hall HFDamp+PreDelay
		MIDI 27	Chorus Mix
		MIDI 28	Chorus Depth
		MIDI 29	Toggle: CDR + Room
84	Hrmnica^Accordin	MWheel	Vibrato
		Data	Toggle: Hrmnica ^ Accordin
		MIDI 22	Layer Switch
		MIDI 23	"InEQ: Bass, Layer Disable, EnvCtl: Rel"
		MIDI 24	InEQ: Treb
		MIDI 25	"(Fx1) Room Wet/Dry, (Aux) Hall Level"
		MIDI 26	"Room Time, Phase FB"
		MIDI 27	"(Aux) Hall adj, Phase Center Freq+LFODepth"
		MIDI 28	(Aux) Hall HFDamp
		MIDI 29	Toggle: Room + Phaser
85	Trmpts^BrBrass	MWheel	Vibrato
		Data	(Brass) HiPass Freq
		MIDI 22	Toggle: Trumpets ^ Brass
		MIDI 23	"(Brass) Filt Freq, InEQ: Bass"
		MIDI 24	EnvCtl: Imp
		MIDI 25	EnvCtl: Rel
		MIDI 26	(Aux) Chamber Level
		MIDI 27	Chamber Time+HFDamp
		MIDI 28	InEQ: Treb
		MIDI 29	Chorus FB
86	Hip Brass	MWheel	Vibrato
		Data	Freq + Res adj
		MIDI 22	InEQ: Treb
		MIDI 23	EnvCtl: Imp
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level
		MIDI 26	"Hall PreDelay Time, (Fx1) Room Time"
		MIDI 27	"(Fx1) Room Wet/Dry+Time, (Fx2) Sweep Filt Res"
		MIDI 28	(Fx2) Sweep Filt LFO Tempo
		MIDI 29	Sweep Filt I/O
87	Brass De' ROM	MWheel	Swell
		Data	"Filt Freq, Swell"
		MIDI 22	"EnvCtl: Imp, Filt Freq + Res"
		MIDI 23	InEQ: Treb + Bass
		MIDI 24	EnvCtl: Dec
		MIDI 25	EnvCtl: Rel
		MIDI 26	"(Aux) Hall Level, InEQ: Bass boost"
		MIDI 27	Hall Time+HFDamp
		MIDI 28	Chorus Mix
		MIDI 29	Delay Mix
88	BigBand^Hornz	MWheel	Hall LP Injection+ PreDelay Time
		Data	"Vibrato, Swell"
		MIDI 22	"Vibrato, LoPass adj (BigBand)"
		MIDI 23	Toggle: BigBand ^ Hornz
		MIDI 24	LoPass Freq Cut (Hornz)
		MIDI 25	"LoPass Res (Hornz), EnvCtl: Att"
		MIDI 26	LoPass ASR (Hornz)
		MIDI 27	(Aux) Room Wet/Dry
		MIDI 28	Room Time
		MIDI 29	Room PreDelay
89	Z-Plane Brass	MWheel	Room HFDamp
		Data	Enhc I/O
		MIDI 22	MPress
		MIDI 23	Vibrato
		MIDI 24	EnvCtl: Att +Dec
		MIDI 25	BandPass Filt Freq + Width
		MIDI 26	"InEQ: Bass, EnvCtl: Rel"
		MIDI 27	InEQ: Treb
		MIDI 28	(Aux) Hall Level
		MIDI 29	Hall Time

85	Trmpts^BrBrass	MWheel	(Brass) HiPass Freq
		Data	Toggle: Trumpets ^ Brass
		MIDI 22	"(Brass) Filt Freq, InEQ: Bass"
		MIDI 23	EnvCtl: Imp
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Chamber Level
		MIDI 26	Chamber Time+HFDamp
		MIDI 27	InEQ: Treb
		MIDI 28	Chorus FB
		MIDI 29	Chorus I/O
		MPress	Swell
86	Hip Brass	MWheel	Vibrato
		Data	Freq + Res adj
		MIDI 22	InEQ: Treb
		MIDI 23	EnvCtl: Imp
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level
		MIDI 26	"Hall PreDelay Time, (Fx1) Room Time"
		MIDI 27	"(Fx1) Room Wet/Dry+Time, (Fx2) Sweep Filt Res"
		MIDI 28	(Fx2) Sweep Filt LFO Tempo
		MIDI 29	Sweep Filt I/O
87	Brass De' ROM	MWheel	Swell
		Data	"Filt Freq, Swell"
		MIDI 22	"EnvCtl: Imp, Filt Freq + Res"
		MIDI 23	InEQ: Treb + Bass
		MIDI 24	EnvCtl: Dec
		MIDI 25	EnvCtl: Rel
		MIDI 26	"(Aux) Hall Level, InEQ: Bass boost"
		MIDI 27	Hall Time+HFDamp
		MIDI 28	Chorus Mix
		MIDI 29	Delay Mix
88	BigBand^Hornz	MWheel	Hall LP Injection+ PreDelay Time
		Data	"Vibrato, Swell"
		MIDI 22	"Vibrato, LoPass adj (BigBand)"
		MIDI 23	Toggle: BigBand ^ Hornz
		MIDI 24	LoPass Freq Cut (Hornz)
		MIDI 25	"LoPass Res (Hornz), EnvCtl: Att"
		MIDI 26	LoPass ASR (Hornz)
		MIDI 27	(Aux) Room Wet/Dry
		MIDI 28	Room Time
		MIDI 29	Room PreDelay
89	Z-Plane Brass	MWheel	Room HFDamp
		Data	Enhc I/O
		MIDI 22	MPress
		MIDI 23	Vibrato
		MIDI 24	EnvCtl: Att +Dec
		MIDI 25	BandPass Filt Freq + Width
		MIDI 26	"InEQ: Bass, EnvCtl: Rel"
		MIDI 27	InEQ: Treb
		MIDI 28	(Aux) Hall Level
		MIDI 29	Hall Time

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
90	OrcBrs^FrenchBone	MWheel	Vibrato
		Data	Toggle: OrcBrs ^ FrenchBone
		MIDI 22	InEQ: Bass
		MIDI 23	"InEQ: Treb, LoPass Freq"
		MIDI 24	EnvCtl: Imp + Rel
		MIDI 25	(Aux) Hall Mix
		MIDI 26	"Hall Time, Mix adj, Pan Rate(Fx3)"
		MIDI 27	Chorus Mix
		MIDI 28	Delay Mix
		MIDI 29	"Hall PreDelay, Pan I/O"
		MPress	"Swell, Vibrato Depth"
91	Brt Saxy Section	MWheel	Vibrato
		Data	"InEQ: Bass, LoPass Freq"
		MIDI 22	InEQ: Treb
		MIDI 23	"EnvCtl: Imp, Att+Dec"
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Room Level
		MIDI 26	"Room Wet/Dry + HFDamp, InEQ: Treb Freq"
		MIDI 27	Dist tube Drive
		MIDI 28	Dist Warmth+Tone
		MIDI 29	"Toggle: Dist+EQ I/O, Room type"
		MPress	Vibrato
92	Brt Saxy/Split	MWheel	Vibrato
		Data	InEQ: Bass+Treb
		MIDI 22	EnvCtl: Imp
		MIDI 23	EnvCtl: Att+Dec
		MIDI 24	EnvCtl: Rel
		MIDI 25	Xfade: (fx1) Chmb + (Aux) Hall
		MIDI 26	Chamb + Hall HFDamp
		MIDI 27	Comp smooth Time
		MIDI 28	Comp signal Delay
		MIDI 29	"Toggle: Chamb + Comp, Hall room size"
		MPress	Vibrato
93	Mr. Parker	MWheel	Vibrato
		Data	LoPass Freq
		MIDI 22	LoPass Res
		MIDI 23	LoPass Freq
		MIDI 24	EnvCtl: Att+Rel
		MIDI 25	(Aux) Plate Wet/Dry
		MIDI 26	Plate Time
		MIDI 27	Chorus Mix
		MIDI 28	Delay Mix (sys)
		MIDI 29	"Plate LFO adj, Delay FB"
		MPress	Vibrato
94	Dynasax	MWheel	"Vibrato, LoPass Freq"
		Data	Layer enable
		MIDI 22	"Layer AltCtl, LoPass Freq, Notch Freq, ParaTreb Freq"
		MIDI 23	"Notch Width, LoPass Res, EnvCtl: Imp+Att"
		MIDI 24	EnvCtl: Dec+Rel
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall HFDamp+Decay Time
		MIDI 27	Chorus Mix
		MIDI 28	Delay (sys) Mix
		MIDI 29	Hall PreDelay + room size adj
		MPress	"Vibrato, LoPass Freq+Res, Shape adj"
		ChanSt	"Layer AltCtl, EnvCtl: Rel"

ID	Name		
95	DynTrumpet^Miles	MWheel	"swell, Vibrato"
		Data	Toggle: DynTrumpet ^ Miles
		MIDI 22	LoPass Freq+Res
		MIDI 23	"EnvCtl: Imp, InEQ: Bass"
		MIDI 24	"EnvCtl: Rel, InEQ: Treb"
		MIDI 25	"(fx1) Chamb Wet/Dry, (Aux) Room Level"
		MIDI 26	Chamb + Room Times
		MIDI 27	"Chamb + Room HFDamp, Dist Drive"
		MIDI 28	Dist LoPass Freq
		MIDI 29	Toggle: Chamb + Dist
		MPress	Vibrato
96	Wawa Trumpet (MW)	MWheel	"BandPass Freq, Vibrato, RevRvb HFDamp"
		Data	BandPass Width
		MIDI 22	Bandpass LFO Rate
		MIDI 23	"EnvCtl: Imp, InEQ: Bass"
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Wet/ Dry+LateTime+Level
		MIDI 26	(fx2) ReverseRvb Wet/Dry
		MIDI 27	ReverseRvb FB
		MIDI 28	"QFlange Wet/Dry, pan"
		MIDI 29	"QFlange I/O, RevRvb adj, Hall cut"
		MPress	Vibrato
97	Almost Muted (MW)	MWheel	"Vibrato, mute adj"
		Data	LoPass Freq
		MIDI 22	HiPass Freq
		MIDI 23	EnvCtl: Imp
		MIDI 24	EnvCtl: Rel
		MIDI 25	(fx1) Room Wet/Dry+Time
		MIDI 26	Room HFDamp
		MIDI 27	InEQ: Bass
		MIDI 28	InEQ: Treb
		MIDI 29	EQMorph I/O
		MPress	Vibrato
98	Solo Trombone	MWheel	Vibrato
		Data	LoPass Freq+Res
		MIDI 22	AltControl
		MIDI 23	EnvCtl: Imp
		MIDI 24	EnvCtl: Rel
		MIDI 25	"(fx1) Chamb Wet/Dry, (Aux) Room Level"
		MIDI 26	Chmb HFDamp
		MIDI 27	InEQ: Treb
		MIDI 28	Dist Drive adj
		MIDI 29	Toggle: Chmb + Dist
		MPress	Vibrato
99	Jazz Band	MW	Tremolo (guitars)
		Data	Toggle: Guitars + Horns
		MIDI 22	Toggle: Band and Drums
		MIDI 23	Tremolo Rate
		MIDI 25	"(Aux) rvb Levels, Wet/Dry"
		MIDI 26	SRS Parameters (guitar layers)
		MIDI 27	(Aux) rvb Times
		MIDI 28	"Early reflection Level, Late Level cut"

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
100	W.C.Flute^Winds	Data	Toggle: W.C. Flute ^ Winds; BndPass adj
		MIDI 22	"Sax / square Layers enable, Pan position, BndPass adj"
		MIDI 23	adds chiff (sax / square inactive)
		MIDI 24	EnvCtl: Dec (sax / square)
		MIDI 25	(Aux) Hall Level cut
		MIDI 26	Booth Wet/ Dry+HFDamp+Absorption; Echo Level+Balance
		MIDI 27	"Echo Wet/Dry, FB"
		MIDI 28	Echo Tempo
		MIDI 29	Toggle: Booth + Echo
		MPress	Vibrato
		MIDI 25	(Aux) Hall Level
101	Baroque Flute	MIDI 26	Hall Time
		MIDI 27	Hall HFDamp
		MIDI 29	"Toggle: Real Room + Perc Room, InEQ: Treb"
102	Synth Caliopies	MW	Vibrato
		Data	Layer disable(up); LoPass Res
		MIDI 22	BandPass Freq; LoPass Freq
		MIDI 23	"LoPass Freq+Res, Hipass Freq, Treb boost"
		MIDI 24	EnvCtl: Att+Rel
		MIDI 25	"(Aux) Hall Level, Room Wet/ Dry"
		MIDI 26	Phaser FB
		MIDI 27	Phaser LFO Rate
		MIDI 29	"Toggle: Room+Phaser(Layer 1+3), Phaser+CDR(Layer 2+4)"
103	Incan	MW	Vibrato
		Data	HiPass Freq
		MIDI 22	Panner LFO amt+speed
		MIDI 23	EnvCtl: Att
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Plate cut
		MIDI 26	Chorus Level+FB
		MIDI 27	Delay FB
		MIDI 28	Delay Time (4 increments)
		MIDI 29	"Toggle: Echo I/O (sys), Plate Time, Delay Mix"
104	String Orchestra	MPress	"HiPass Freq LFO amt, Pitch fall"
		Data	Toggle: Layers
		MIDI 22	"LoPass Freq cutoff, Bass boost"
		MIDI 23	EnvCtl: Att
		MIDI 25	(FX1) Hall Wet/Dry+PreDelay
		MIDI 26	Hall Time
		MIDI 27	Hall HFDamp
		MIDI 28	(Layer 2) InEQ: Treb cut
105	ClassicalStrings	MPress	(Layer 2) volume swell
		MW	(Layer 3+4) LoPass separation
		Data	"Toggle: Layers1+2, 3+4"
		MIDI 22	(Layer 1+2) LoPass Freq
		MIDI 23	(Layer 3+4) LoPass Freq+Res cut
		MIDI 24	EnvCtl: Att
		MIDI 25	(FX1) Hall Wet/Dry
		MIDI 26	Hall Time
		MIDI 27	Hall HFDamp
		MIDI 28	Hall PreDelay

ID	Name		
106	StSloStr^SilkStr	MW	Layer balance
		Data	Toggle: StSloStr ^ SilkStr
		MIDI 22	"Layer Delay, LoPass Freq+Res "
		MIDI 23	"EnvCtl: Att, LoPass Freq"
		MIDI 24	"EnvCtl: Att+Dec+Rel, LoPass Freq cut"
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Time
		MIDI 27	(FX1) Chapel Level
		MIDI 28	Chapel Time
		MPress	"Vibrato, Shaper amt"
		MW	Vibrato ^ Flange Rate
107	BigStrgs^FlingStrg	Data	Toggle: BigStrgs ^ FlingStrg
		MIDI 22	(Layer 1) octave jump
		MIDI 23	EnvCtl: Att
		MIDI 25	(Aux) Hall Level
		MIDI 26	(Aux) Hall Time ^ Phaser CtrFreq
		MIDI 27	Flange FB
		MIDI 28	Flange Rate+L/R phase
		MIDI 29	Toggle: Flange I/O (BigStrgs)
		MPress	"Vibrato, InEQ: Treb"
		MW	Chorus Mix
108	Chamber Ensemble	Data	AllPass Freq
		MIDI 23	EnvCtl: Att
		MIDI 24	InEQ: Bass+Treb
		MIDI 25	"(Aux) Hall Level+PreDelay, (fx1) Hall Mix"
		MIDI 26	Delay Mix+FB
		MIDI 27	Delay Tempo cut
		MIDI 28	(Aux) Hall Time+HFDamp+Injection
		MPress	"Vibrato, AllPass Freq"
		MW	(Vln1)EnvCtl: Att
		Data	"Toggle: Psuedo Violin1 ^ 2, (Vln2) EnvCtl: Att"
109	Psuedo Violin1^2	MIDI 22	(Vln1) LoPass Freq cut
		MIDI 23	(Vln2) LoPass Freq cut
		MIDI 24	(Vln1) Shaper Level
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall LateRvbTime+HFDamp
		MIDI 27	(FX1) Room Wet/Dry
		MPress	Vibrato
		MW	LoPass sep (expReasion / dynamic ctl)
110	Slo Solo Cello	Data	LoPass Freq cut+Res cut
		MIDI 22	EnvCtl: Att+Dec
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall LateRvbTime+HFDamp
		MIDI 27	(FX1) Room Wet/Dry
		MIDI 28	Room HFDamp
		MIDI 29	"Toggle: Room type, Hall Wet/ Dry"
		MPress	Vibrato

ID	Name		
111	Horn&Flute w/Str	MW	"Vibrato, LoPass sep (expression / dynamic ctl)"
		Data	Toggle: Horn ^ Solo String
		MIDI 22	LoPass Freq+Res cut
		MIDI 23	Ens Strings Vol cut
		MIDI 24	Ens Strings EnvCtl: Att
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Time
		MIDI 27	(FX1) Chapel Wet/Dry
		MIDI 28	Chapel Time
		MIDI 29	"Toggle: (Layer 3+4) Chapel+Hall, (Layer 1) Hall+Chapel"
		MPress	Ens Strings Vibrato
		SostPd	Toggle: Solo Strg I/O
112	DynOrch^WTellOrc	MW	string and brass balance
		Data	Toggle: DynOrch ^ WTellOrch
		MIDI 22	"ParaMid and LoPass Freq, Shaper Drive"
		MIDI 23	"Shaper amt, LoPass Freq"
		MIDI 25	(Aux) Hall Level cut
		MIDI 26	Chapel + Hall Times
		MIDI 29	Toggle: Chapel/Hall + Hall/ Room
		MPress	"(DynOrch) Volume swell, shaper amt"
		SostPd	"Layer enable, Room Time"
113	Touchy Orchestra	MW	"Bone cut, LoPass Freq(Lo Strings)"
		Data	Hi String cut
		MIDI 22	Lo String ^ Hi Flute
		MIDI 23	Timpani cut
		MIDI 24	Loud Horn ^ Soft Horn
		MIDI 25	"(Aux) Hall Level, Chapel + Rooms Wet/Dry"
		MIDI 26	Chapel Time
		MIDI 29	"Toggle: Chapel+Room, Hall+Chapel"
		MPress	Hi Flute Vibrato Rate
114	Synth Strings	MW	"Vibrato, modulation"
		Data	Toggle: Layer 1 ^ Layer 3
		MIDI 22	Layer 1 up p5th ^ Layer 3 up 8ve
		MIDI 23	EnvCtl: Att
		MIDI 24	EnvCtl: Imp+Rel
		MIDI 25	(Aux) Plate Level
		MIDI 26	"Chorus Wet/Dry, Dist Drive"
		MIDI 27	Chorus FB
		MIDI 28	Dist Bass+Treb tone
		MIDI 29	Toggle: Chorus + Distortion
115	Mellostr^ShineOn	MW	Vibrato
		Data	Toggle: Mellostr ^ ShineOn
		MIDI 22	LoPass+BandPass Freq+Width
		MIDI 23	"EnvCtl: Att, LoPass Res"
		MIDI 24	EnvCtl: Rel
		MIDI 25	"(Aux) Room Level, Hall absorption"
		MIDI 26	"Filt Res, Chorus FB"
		MIDI 27	"Filt Freq, Chorus Rate"
		MIDI 28	"Filt Vibrato, Delay Mix"
		MIDI 29	Toggle: Res Filt + ChorDelay (Mellostr only)
		MPress	"Vibrato, HiPass Freq"

ID	Name		
116	Mellotron (MW)	MW	"3-way toggle: Ens Strg, Solo Strg(dwn 8ve), Flute"
		Data	Octave jump
		MIDI 22	LoPass Freq; ParaTreb Freq ; HiFreqStim Freq
		MIDI 23	"Dist Drv, Xfade dpth; ParaTreb dpth; HFStim Drv"
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Time
		MIDI 27	Room Level
		MIDI 28	Room Time
		MPress	Vibrato
117	RaveStrg^Solina	MW	"Vibrato, Layer detune(Sol)"
		Data	Toggle: RaveStrg ^ Solina
		MIDI 22	EnvCtl: Att+Rel
		MIDI 23	"EnvCtl: Dec ^ Ptch mod, Notch LFO Rate"
		MIDI 24	"Flange Mix, Spin Wet/Dry"
		MIDI 25	(Aux) Room Level
		MIDI 26	Spin Pitcher Mix ^ MovDelay Wet/Dry
		MIDI 27	Spin Pitcher Weights
		MIDI 28	Spin Pitcher ptch (rapid echo Rate)
		MIDI 29	"Toggle: Spin I/O, Room HFDamp+Time"
118	Choir Strings	MW	Vibrato
		Data	LoPass Freq cut+Res (string)
		MIDI 22	LoPass Freq cut (vox)
		MIDI 23	"Layer detune, LoPass Res"
		MIDI 24	Panner Width
		MIDI 25	(Aux) Room Level
		MIDI 26	(Aux) Room Time
		MIDI 27	Flange Level
		MIDI 28	Flange Tempo
		MIDI 29	"Toggle: Room + Flange (string), ChHall + Hall (vox)"
119	CathdrVox^8veVox	MW	"Vibrato+Rate (CathV), Sin Tremolo Rate (8veV)"
		Data	Toggle: CathedralVox ^ 8veVox
		MIDI 22	"EnvCtl: Att, LoPass Freq, Xfade Lo/Hi Vox(8veV)"
		MIDI 23	"EnvCtl: Rel, Panner pos, 8ve jump(CathV)"
		MIDI 24	InEQ: Treb cut
		MIDI 25	(Aux) Hall Level
		MIDI 26	(Aux) Hall Time+build Time
		MIDI 27	Delay Mix+FB
		MIDI 28	Flange Mix+FB
		MPress	"Vibrato+Rate (CathV), Sin Tremolo Rate (8veV)"
120	Mixed Choir	MW	Vibrato+Rate
		Data	Layer XFade
		MIDI 22	"EnvCtl: Rel, Notch + ParaTreb Freq"
		MIDI 23	"InEQ: Bass, ParaTreb, Notch Width"
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Level
		MIDI 26	Room Wet/Dry
		MIDI 27	Room Time
		MIDI 28	Infinite Decay on Keydown
		MIDI 29	Infinite Decay
		MPress	Vibrato+Rate

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
121	NUChoir^SpaceVox	MW	Vibrato
		Data	Toggle: NUChoir ^ SpaceVox
		MIDI 22	"EnvCtl: Att, Shaper amt ^ LoPass Freq"
		MIDI 23	EnvCtl: Rel
		MIDI 24	LoPass Freq (SpaceVox)
		MIDI 25	(Aux) Hall: Level+buildTime+DecayTime+PreDelay+HFDamp
		MIDI 26	(Aux) Hall Bass gain
		MIDI 27	InEQ: Bass
		MIDI 28	InEQ: Treb
		MIDI 29	Toggle: (Aux) Hall I/O (SpaceVox)
		MPress	Vibrato
122	Marimbae^Vibeish	MW	"Layer 2 alt Toggle, EnvCtl: Rel, Tremolo, Panner pos"
		Data	Toggle: Marimbae ^ Vibish
		MIDI 22	"Xfade: Layer 1+2, Layer detune, LP / HPass freq, HFStim Drive"
		MIDI 23	"Layer 2 alt Toggle, EnvCtl: Rel"
		MIDI 24	EnvCtl: Imp+Dec
		MIDI 25	"(Aux) Hall Level, Room Wet/Dry"
		MIDI 26	Hall+Room Times
		MIDI 29	Toggle: Room + Compressor/ Hall ^ Room I/O
123	SlidersIn Africa	MW	"Layer 2 Xfade, Panner Pos"
		Data	LoPass Freq cut
		MIDI 22	HiPass Freq
		MIDI 23	Panner LFO amt+Pos
		MIDI 24	Pitch drop
		MIDI 25	Delay Time
		MIDI 26	Delay FB
		MIDI 27	Laser Contour
		MIDI 28	Laser Spacing
124	MalletFlts Split	MW	Pitch up (Layer1+6)
		Data	Layer5 Enable
		MIDI 22	"LoPass Freq+Res, Shape mod (Layer 4), ParaTreb boost"
		MIDI 23	"HiPass Freq (Layer3), Shaper amt, Notch Freq (Layer 4), Panner Pos(Layer 3)"
		MIDI 25	(Aux) Space Rvb Level+Mix+Time
		MIDI 26	Delay Mix
		MIDI 27	Delay Time
		MIDI 29	"Toggle: CDR + Chorus, (Layers 1, 2, 6)"
		MPress	Notch Freq
125	Malletoo	MW	"Pitch modulation, Vibrato"
		Data	"Pitch mod LFO speed, LoPass Freq (Layer 3)"
		MIDI 22	LoPass Res cut (Layer 3)
		MIDI 23	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level+Time+HFDamp
		MIDI 26	(Aux) Delay Mix cut
		MIDI 27	Flange Wet/Dry
		MIDI 28	Flange FB
		MIDI 29	Toggle: Flange I/O
		MPress	Vibrato

126	Highlandistic	MW	(Aux) Hall Infinite Decay Vibrato
		Data	EnvCtl: Rel
		MIDI 22	ParaTreb Freq
		MIDI 23	"InEQ: Bass, Notch+HiPass Freq"
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Level
		MIDI 26	"Hall Time+HFDamp, Chorus Mix"
		MIDI 27	Delay Mix+FB
		MIDI 28	Chorus Level cut
		MIDI 29	Toggle: Infinite Decay I/O
		MPress	Vibrato
127	Buzz Kill	MW	Pitch modulation
		Data	LoPass Freq
		MIDI 22	"LoPass Res cut, Dist Drive cut"
		MIDI 23	"EnvCtl: Att, Flange LFO"
		MIDI 24	"EnvCtl: Rel, Flange L/R phase"
		MIDI 25	Flange Delay Tempo
		MIDI 26	Flange FB
		MIDI 27	(Aux) CDR Level cut
		MIDI 28	(Aux) Delay Mix
		MIDI 29	(Aux) Hall Wet/Dry+Time adj
128	Harshey's	MW	Pitch modulation
		Data	LoPass Freq
		MIDI 22	"LoPass Res cut, Dist Drive cut"
		MIDI 23	"EnvCtl: Att, Flange LFO"
		MIDI 24	"EnvCtl: Rel, Flange L/R phase"
		MIDI 25	"Flange Wet/Dry, (Aux) Delay Tempo"
		MIDI 26	Flange FB
		MIDI 27	(Aux) CDR Level
		MIDI 28	(Aux) Delay Mix
		MIDI 29	(Aux) Hall Wet/Dry+Time adj
129	Spunter	MW	Pitch octave jump
		Data	"EnvCtl: Dec, Rel"
		MIDI 22	Pitch octave+jump
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Level+Mix
		MIDI 26	Hall Time
		MIDI 27	(Aux) Delay Mix+Dry Balance
		MIDI 28	Distortion Wet/ Dry+Warmth+HiPass
130	Crumper	MW	Vibrato
		Data	EnvCtl: Att+Rel
		MIDI 22	DSP Xfade: SW+SHP
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Mix+Time+PreDelay
		MIDI 26	(Aux) Delay Mix
		MIDI 27	Dist Drive
		MIDI 28	Dist Warmth
		MIDI 29	Toggle: Delay I/O
		MPress	Vibrato

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
131	Zeek	MW	Pitch modulation
		Data	LoPass Freq cutoff
		MIDI 22	"LoPass env amt, 8ve jump"
		MIDI 23	EnvCtl: Att
		MIDI 24	EnvCtl: Rel
		MIDI 25	(FX2) Room Wet/Dry cut
		MIDI 26	Room Time
		MIDI 27	Dist Wet/Dry
		MIDI 28	(Aux) GrphEQ I/O
		MIDI 29	Toggle: AClock Amp modulation I/O
132	Elephantiasis	MW	HiPass Freq
		Data	HiPass Freq
		MIDI 22	Pitch
		MIDI 23	EnvCtl: Att
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) EQ 1k Level
		MIDI 26	(Aux) EQ 2k Level
		MIDI 27	(Aux) EQ 4k Level
		MIDI 28	(Aux) EQ 8k Level
		MIDI 29	(Aux) Level cut
133	SoftMatrix12 5th	MW	Vibrato
		Data	"LoPass Freq, EnvCtl: Att+Dec"
		MIDI 22	Pitch drop
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Plate Level
		MIDI 26	Plate HFDamp+Decay Time
		MIDI 27	Echo Wet/Dry
		MIDI 28	Echo FB
		MIDI 29	"Toggle: Echo I/O, Plate room size adj"
134	TchRezoid^Hungry	GAttVel	Echo HFDamp
		MPress	Vibrato
		MW	"Vibrato, Phaser Ctr Freq"
		Data	Toggle: TchRezoid (EnvCtl: Att+Dec) ^ Hungry (EnvCtl: Rel)
		MIDI 22	"HiPass Res, Wrap amt ^ LoPass Res, "
			"Saw+Shp 8ve jump, Xfade: triangle+saw"
		MIDI 23	HiPass sep ^ EnvCtl: Att
		MIDI 24	EnvCtl: Rel ^ EnvCtl: Imp
		MIDI 25	AstralTaps Wet/Dry+FB
		MIDI 26	(Aux) Phaser Level
135	Matchstik^NUDigi	MIDI 27	"Phaser Notch, BandPass adj"
		MIDI 28	AstralTaps Tempo
		MPress	Vibrato
		MW	"Vibrato, Phaser Ctr Freq"
		Data	Toggle: MatchStik ^ NUDigi
		MIDI 24	(Aux) Phaser Level+FB cut
		MIDI 25	(Aux) Phaser Notch/ BP
		MIDI 26	AstralTaps Wet/Dry+FB
		MIDI 27	AstralTaps FB image
		MIDI 28	AstralTaps Tempo

ID	Name		
136	Peppers Digiclub	MW	"Pitch chng+mod, LFO Depth(VAST+(Aux) Hall)"
		Data	LoPass Freq
		MIDI 22	"Pitch jump, Pitch LFO Rate Toggle"
		MIDI 23	EnvCtl: Att
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level (MIDI 29 out)
		MIDI 26	(Aux) Hall Time
		MIDI 27	Flange Wet/Dry
		MIDI 28	Flange Feedback
		MIDI 29	"(Aux) Hall Level+Mix+LFO Depth+Rate, Flange Dry cut"
137	Frog^LowNoteTalk	MPress	Pitch changes
		MW	Vibrato
		Data	Xfade: Frog ^ LowNoteTalk
		MIDI 22	"Pitch Drop, Wrap amt"
		MIDI 23	ShpOsc Depth ^ Wrap amt
		MIDI 24	BandPass+AllPass Freq
		MIDI 25	"EQ Morph ""A"" Freq scale"
		MIDI 26	"EQ Morph ""B"" Freq scale"
		MIDI 27	Echo Wet/Dry
		MIDI 28	Echo FB
138	Oink Doink	MIDI 29	Toggle: EQ Morph + Echo
		MPress	Vibrato
		MW	Vibrato
		Data	EnvCtl: Att+Dec
		MIDI 22	HiPass Res cut
		MIDI 23	"InEQ: Bass, HiPass separation"
		MIDI 24	"InEQ: Treb, EnvCtl: Imp"
		MIDI 25	(Aux) Hall Level
		MIDI 26	(Aux) Delay Level
		MIDI 27	Laser spacing
139	Wheepy Dood	MIDI 28	Laser Contour
		MIDI 29	Toggle: Laser I/O
		MPress	Vibrato
		LgeRbn	Laser Delay Coarse
		MW	Vibrato
		Data	LoPass Freq
		MIDI 23	EnvCtl: Att+Dec
		MIDI 24	EnvCtl: Rel
		MIDI 25	Chorus Mix+Delay
		MIDI 26	Chorus Depth+Rate
140	Funk O Matic	MIDI 27	Chorus FB
		MIDI 28	Delay Mix+FB
		MPress	Vibrato
		MW	"Vibrato, Vibrato Rate"
		Data	LoPass Freq
		MIDI 22	"Shaper amt, LoPass Freq cut"
		MIDI 23	Dist Drive
		MIDI 24	(Layer 1+3) 8ve drop
		MIDI 25	Env Filt thReshold
		MIDI 26	Env Filt min Freq
		MIDI 27	(Aux) Sweep Filt Wet/Dry
		MIDI 28	(Aux) Sweep Filt min Freq
		MIDI 29	Toggle: Env Filt - BandPass and HiPass
		MPress	"Vibrato, Layer detune"

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
141	Pulsemonster5ths	MW	Vibrato
		Data	"PWM Width, LoPass Freq, Dist Drv cut"
			EnvCtl: Att+Dec+Rel
		MIDI 22	Dist Drv cut
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Level
		MIDI 26	"(Aux) Hall PreDelay, Decay Time, HFDamp, Bass gain"
		MIDI 27	Chorus Depth
		MIDI 28	Delay Mix+FB
142	OB Pad^OB Brass	MW	Vibrato
		Data	Toggle: OBPd ^ OB Brass
			"LoPass Freq, EnvCtl: Att+Rel (pad)"
		MIDI 22	LoPass Res ^ LoPass Freq
		MIDI 23	EnvCtl: Imp (brass)
		MIDI 24	(Aux) Plate Level+Time
		MIDI 25	"Enhc Lo Drive+Mix, Chorus Wet/Dry "
		MIDI 26	"Enhc Mid Drive, Mid Mix"
		MIDI 27	"Enhc Hi Drive, Hi Mix, InEQ: Treb"
		MIDI 28	Toggle: Enhancer + Chorus
143	Detooner^BigPMW	MW	Vibrato
		Data	Toggle: Detooner ^ BigPMW
			"P5th jump ^ LoPass Freq, EnvCtl: Att+Rel"
		MIDI 22	"Notch Freq ^ Dist drv, EnvCtl: Imp"
		MIDI 23	"PWM Width, Dist drv"
		MIDI 24	(Aux) Laser Level
		MIDI 25	(Aux) Laser contour+FB
		MIDI 26	"Flange FB+L/R phase, Phaser Ctr Freq"
		MIDI 27	"Flange Wet/Dry cut, Phaser Wet/Dry"
		MIDI 28	Toggle: Flange + Phaser
144	TeknoBallCrusher	MW	Vibrato
		Data	"EnvCtl: Att, Notch Freq"
		MIDI 22	saw 8ve jump (Layer 1)
		MIDI 23	EnvCtl: Impact
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Room Level
		MIDI 26	Chorus Wet/Dry; Dist Drive cut
		MIDI 27	Chorus Rate; Dist warmth cut
		MIDI 28	Chorus FB; Dist cab LoPass
		MIDI 29	Toggle: Chorus + Distortion
145	VTrig SquareHead	MW	Vibrato
		Data	BandPass Freq Env amt+Width
			"EnvCtl: Imp, Saw Pitch, InEQ: Bass "
		MIDI 23	"EnvCtl: Rel, InEQ: Treb"
		MIDI 24	(Aux) Delay Mix
		MIDI 25	(Aux) Chorus Mix
		MIDI 26	Phaser FB cut
		MIDI 27	Phaser Ctr Freq
		MIDI 28	(Aux) Chorus Delay cut
		MIDI 29	Vibrato

ID	Name		
146	Razor Saw	MW	Vibrato
		Data	"LoPass LFO Rate, Shaper amt, EnvCtl: Att+Dec "
		MIDI 22	EnvCtl: Rel
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
			(Aux) Hall Level+PreDelay+Time+HFDamp
		MIDI 25	Delay FB+Mix
		MIDI 26	Chorus Depth+Rate
		MIDI 27	Chorus FB
		MIDI 28	Toggle: Delay I/O
147	Razorip Buzzsaw	MW	Vibrato
		Data	"EnvCtl: Rel, HiPass Freq"
		MIDI 22	Sine Pitch
		MIDI 23	Saw+Sine Pitch
		MIDI 24	InEQ: Bass+Treb
		MIDI 25	(Aux) Hall Time+HFDamp
		MIDI 26	(Aux) Delay Mix
		MIDI 27	Phaser FB cut
		MIDI 28	Phaser Ctr Freq+LFO Rate
		MIDI 29	(Aux) Chorus Delay adj
148	Pulse Pass	MW	Vibrato
		Data	HiPass Freq
		MIDI 22	PWM Width
		MIDI 23	EnvCtl: Imp
		MIDI 24	"EnvCtl: Att+Rel, Dist drv cut"
			(Aux) Hall Level+Time, Delay HFDamp
		MIDI 25	Delay Mix
		MIDI 26	Chorus Rate+Depth
		MIDI 27	Chorus FB
		MIDI 28	(Aux) Hall PreDelay adj
149	Nordic Square	MW	Vibrato
		Data	Lo+Hi Pass Freq cut
		MIDI 22	EnvCtl: Att
		MIDI 23	EnvCtl: Imp
		MIDI 24	EnvCtl: Rel
			(Aux) Hall Level; Flange/ Dry>Delay Mix
		MIDI 25	"Chorus Mix, Depth+Delay"
		MIDI 26	Chorus Rate+FB
		MIDI 27	Delay Mix+FB
		MIDI 28	Toggle: ChorusDelay/(Aux) Hall + Flange/Delay
150	Rezonant Snob	MW	Vibrato
		Data	Filt LFO
		MIDI 22	Filt Res
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Wet/Dry
		MIDI 26	Hall Time
		MIDI 27	Hall preDelay+HFDamp
		MIDI 28	Delay Mix
		MIDI 29	Toggle: Delay Time cut+HFDamp adj
151	Vibrato	MW	Vibrato
		Data	Filt LFO
		MIDI 22	Filt Res
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Wet/Dry
		MIDI 26	Hall Time
		MIDI 27	Hall preDelay+HFDamp
		MIDI 28	Delay Mix
		MIDI 29	Toggle: Delay Time cut+HFDamp adj

ID	Name		
151	Borfin'Jumps^RPT	MW	"EnvCtl: Att+Dec, Rel"
		Data	Toggle: Borfin'Jumps ^ RPT
		MIDI 22	Pitch jump
		MIDI 23	"LoPass Res, "
		MIDI 24	"KDFX InEQ: Treb, Env Ctl (Impact), Amp modulation"
		MIDI 25	"(Aux) rvb Level + Time, PreDelay Time"
		MIDI 26	"Delay Mix, Chorus Delay Time"
		MIDI 27	Phaser FB
		MIDI 28	Phaser LFO Rate
		MIDI 29	Phaser Notch/BandPass balance
		MPress	Phaser LFO Rate
152	Elektro Funk	MW	Modulation
		Data	"Synch slave de-tune, Notch Freq"
		MIDI 22	Synch Master de-tune
		MIDI 23	EnvCtl Att
		MIDI 24	EnvCtl Rel
		MIDI 25	(Aux) Hall Level
		MIDI 26	"Hall Time, size"
		MIDI 27	Vibrato Phaser Wet/Dry
		MIDI 28	"Vibrato Phaser Width, InEQ: Treb"
		MIDI 29	Toggle: Echo on
		MPress	
153	Acid	MW	Pitch up
		Data	HiPass Freq
		MIDI 22	LoPass Res Freq
		MIDI 23	LoPass Res env
		MIDI 24	EnvCtl: Rel
		MIDI 25	Shaper Mid amount
		MIDI 26	Delay Level
		MIDI 27	Delay FB
		MIDI 28	Delay Time
		MIDI 29	Toggle: (Aux) Hall Level boost
154	Rancid	MW	Pitch adj
		Data	HiPass Freq
		MIDI 22	LoPass Res Freq
		MIDI 23	LoPass Res env amt
		MIDI 24	EnvCtl: Rel
		MIDI 25	Shaper Mid amount
		MIDI 26	Echo Level
		MIDI 27	Echo FB
		MIDI 28	Echo Time
		MIDI 29	Toggle: (Aux) Hall Level boost
155	Fuse	MW	System-Synched modulation
		Data	LoPass Freq
		MIDI 22	Lo pass Res cut
		MIDI 23	Pitch drop ASR
		MIDI 24	EnvCtl: Rel
		MIDI 25	Env Filt amt
		MIDI 26	Env Filt min Freq
		MIDI 27	InEQ: Bass
		MIDI 28	InEQ: Treb
		MIDI 29	Toggle: Sweep Filt I/O
		MPress	Gain boost

ID	Name		
156	Squwee Monosync	MW	Vibrato
		Data	Layer enable
		MIDI 22	EnvCtl: Att
		MIDI 23	EnvCtl: Dec
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Booth Level
		MIDI 26	"Gated rvb Wet/Dry cut, Flange Level cut"
		MIDI 27	"Gated rvb size scale, Echo Level"
		MIDI 28	"Echo HFDamp, Echo Level + FB"
		MIDI 29	Toggle: Gated rvb + FlangeEcho
		MPress	Vibrato
157	Generic Ravelead	MW	Pitch mod
		Data	"LoPass Freq cut, EnvCtl: Att+Dec"
		MIDI 22	"LoPass Res, HiPass Freq"
		MIDI 23	LoPass Res cut
		MIDI 24	"Samp alt start, EnvCtl: Imp"
		MIDI 25	(Aux) Booth Level
		MIDI 26	"Echo Wet/Dry, LFO Filt pulse Width"
		MIDI 27	"Echo FB, LFO Filt smooth"
		MIDI 28	"Echo HFDamp, LFO Filt Res"
		MIDI 29	Toggle: Echo + LFO Filt
		MPress	Vibrato
158	Notch Sinker	MW	Vibrato
		Data	EnvCtl: Att+Dec
		MIDI 22	SyncM Pitch adj
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Booth Level
		MIDI 26	"Shaper Wet/Dry cut, Reverse rvb Wet/Dry"
		MIDI 27	"Shaper amount, Reverse rvb envelope"
		MIDI 28	"Reverse rvb length, Delay length"
		MIDI 29	"Toggle: shaper + reverse rvb, (Aux) Booth type+Time"
		MPress	Vibrato
159	Grungesync Sweep	MW	Vibrato
		Data	EnvCtl: Att+Dec
		MIDI 22	Layer LoPass Freq cut
		MIDI 23	Saw wave Pitch jump
		MIDI 24	EnvCtl: Imp
		MIDI 25	(Aux) Hall Level
		MIDI 26	Flange Level
		MIDI 27	"Shaper Level, Quantize Wet/Dry"
		MIDI 28	Shaper amount
		MIDI 29	"Toggle: ShaperFlange + QuantizeFlange, (Aux) Hall Time"
		MPress	Vibrato

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
160	Rezzysaws	MW	Vibrato
		Data	LoPass Freq
		MIDI 22	EnvCtl: Att
		MIDI 23	Saw wave Pitch adj
		MIDI 24	EnvCtl: Imp
		MIDI 25	"(Aux) Hall Level, Wet/Dry"
		MIDI 26	"EnvFilt thReshold, Chorus Level"
		MIDI 27	"EnvFilt sweep, Delay Level"
		MIDI 28	"EnvFilt min Freq, Delay Time"
		MIDI 29	Toggle: EnvFilt + ChorDelay
		MPress	Vibrato
		MW	"Pitch adj, Vibrato"
161	Prophet Sync	Data	"LoPass Freq + Res, Sync slave Pitch, Layer EnvCtl: Rel"
		MIDI 22	Layer Pitch adj
		MIDI 23	InEQ: Treb
		MIDI 24	EnvCtl: Att + Imp
		MIDI 25	(Aux) rvb Level + HFDamp
		MIDI 26	"FX2 Flange Level, FX3 Flange Wet/Dry"
		MIDI 27	"Shaper Level, Quantize Wet/Dry"
		MIDI 28	Shaper amount
		MIDI 29	Toggle: FlangeShaper + QuantizeFlange
		MPress	Pitch mod
		MW	"LoPass LFO Rate, Vibrato"
		Data	LoPass Freq LFO amt
162	Glider	MIDI 22	LoPass Res
		MIDI 23	Notch Freq
		MIDI 24	"Flange FB, EnvCtl: Imp"
		MIDI 25	(Aux) LaserDelay Level
		MIDI 26	"Flange Wet/Dry, Phaser Wet/Dry"
		MIDI 27	LaserDelay Time
		MIDI 28	LaserDelay FB
		MIDI 29	"Toggle: Flange + Phaser, LaserDelay adj"
		MPress	Vibrato
		MW	Toggle: Alaska + Glide
		Data	EnvCtl: Imp
		MIDI 22	EnvCtl: Att
163	AlaskaGlide (MW)	MIDI 23	EnvCtl: Dec
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Levels
		MIDI 26	FDR Wet/Dry
		MIDI 27	InEQ: Bass
		MIDI 28	InEQ: Treb
		MIDI 29	FlgDelayrvb I/O
		MPress	"Vibrato, Layer detune, LoPass Freq, Flange XCurs + FB"
		MW	Vibrato
		Data	Toggle: RaveClassic + Braz
		MIDI 22	"EnvCtl: Imp ^ NotchFilt Freq, EnvCtl: Imp"
		MIDI 23	EnvCtl: Dec ^ EnvCtl: Att+Dec
164	RaveClassic^Braz	MIDI 24	EnvCtl: Rel ^ EnvCtl: Rel
		MIDI 25	"Hall Mix + Time, Delay Mix"
		MIDI 26	Panner LFO Rate
		MIDI 27	Pan image Width
		MIDI 28	Delay Tempo
		MIDI 29	Echo I/O
		MPress	Vibrato

ID	Name		
165	Meditator^SloEns	MW	"Vibrato, LoPass Res"
		Data	Toggle: Meditator + SloEns
		MIDI 22	"LoPass Freq + Res, HFstim adj, Layer Pitch adj"
		MIDI 23	"BandPass Freq, Layer Pitch adj (SloEns)"
		MIDI 24	"Layer Shape adj, EnvCtl: Imp"
		MIDI 25	(Aux) Hall Level + Decay Time ^ Minivrb Level
		MIDI 26	Flang Wet/Dry ^ Minivrb Time + PreDelay
		MIDI 27	Flange FB
		MIDI 28	Delay FB
		MIDI 29	Toggle: Flange + CDR
		MPress	Vibrato
		AttVel	EnvCtl: Rel
166	Tranquil Picked	MIDI 70	"AltCtl, EnvCtl: Imp"
		MW	"Vibrato, Notch Freq env amt"
		Data	"Layer LoPass Freq + Xfade, AllPass Freq, Notch Width, EnvCtl: Rel"
		MIDI 22	"Layer HiPass Freq, Pan adj, AllPass Freq"
		MIDI 23	"Layer Pitch adj, AllPass adj"
		MIDI 24	"Layer Pitch env, EnvCtl: Att"
		MIDI 25	(Aux) Echo Level
		MIDI 26	Flange Wet/Dry
		MIDI 27	Laser coarse Delay
		MIDI 28	Laser contour
		MIDI 29	Toggle: Flange + LaserVrb
		MPress	Vibrato
167	The Chaser	MWheel	Vibrato
		Data	"LoPass Freq, EnvCtl: Att+Dec+Rel"
		MIDI 22	LoPass Freq+Res
		MIDI 23	"HFstim adj, Dist Drive"
		MIDI 24	PWM Width
		MIDI 25	"Rooms Wet/Dry (FX1,FX2)"
		MIDI 26	Rooms HFDamp+Time
		MIDI 27	(Aux) Hall Level
		MIDI 28	Hall HFDamp
		MIDI 29	Toggle: Rooms
		AttVel	AltCtl
		KeyNum	"HFstim LFO, BandPass Width, Notch Freq"
168	Enterprize^MTree	MPress	Vibrato
		MWheel	"Vibrato, Tremolo"
		Data	Toggle: Enterprize ^ MTree
		MIDI 22	"Pitch jump, HFStim ^ EnvCtl: Att+Dec"
		MIDI 23	"HiPass Freq, Dist Drive (VAST)"
		MIDI 24	"DSP XFade, Pitch adj, EnvCtl: Rel"
		MIDI 25	(Aux) Acid Room Level
		MIDI 26	"Acid dry Level cut, Dist Drive adj ^ LasrVrb Wet/Dry"
		MIDI 27	Dist warmth ^ LasrVrb Delay Time
		MIDI 28	Dist Freq adj ^ LasrVrb contour
		MIDI 29	Distortion I/O
		MPress	"Vibrato, Tremolo"
		AttVel	EnvCtl: Rel

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
169	Orgazmica	MWheel	Layer detune
		Data	LoPass Freq cut
		MIDI 22	Pitch octave adj
		MIDI 23	"EnvCtl: Att, HiPass Freq"
		MIDI 24	"EnvCtl: Rel, LoPass Res"
		MIDI 25	"(Aux) Booth Level, (FX1) Room Wet/Dry"
		MIDI 26	Hall HFDamp+Absorption+Time
		MIDI 27	Tremolos
		MIDI 28	Flange FB + Wet/Dry
		MIDI 29	Toggle: (FX1) Room I/O
170	Universal	MWheel	Vibrato
		Data	Pitch adj
		MIDI 22	Amp gain
		MIDI 23	Pitch adj
		MIDI 24	"Saw detune, Pan adj, Square Level"
		MIDI 25	(Aux) Hall Level
		MIDI 26	Flange FB
		MIDI 27	Flange LFO Tempo
		MIDI 28	Flange Xcouple
		MIDI 29	"Toggle: Room + Flange, Hall Decay Time"
171	Asian Digital	MWheel	"Vibrato, Shaper Level"
		Data	EnvCtl: Att+Dec
		MIDI 22	SW+SHP Pitch+pan+Level
		MIDI 23	EnvCtl: Imp+Dec
		MIDI 24	(Aux) Delay FB
		MIDI 25	(Aux) Hall Mix+Time
		MIDI 26	(Aux) Chorus FB
		MIDI 27	Flange Wet/Dry
		MIDI 28	Flange FB+phase
		MIDI 29	Toggle: Flange I/O
172	Wheel Wave Sweep	MWheel	"Layer Xfade, vib, Pan LFO, BandPass Width"
		Data	"BandPass Freq+Width, LoPass + HiPass adj"
		MIDI 22	"LoPass Res, HiPass Res, Pan adj"
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Time+HFDamp
		MIDI 27	Flange FB Level
		MIDI 28	Flange LFO Tempo
		MIDI 29	Toggle: Flange I/O
173	Arystal^InTheAir	MWheel	Vibrato
		Data	Toggle: Arystal ^ InTheAir
		MIDI 22	Layer Pitch adj ^ LoPass adj
		MIDI 23	"LoPass Freq ^ Saw Pitch, Layer detune"
		MIDI 24	"Layer Pitch adj, Layer Xfade"
		MIDI 25	(Aux) Hall Level+Time
		MIDI 26	Chorus Wet/Dry
		MIDI 27	Chorus FB
		MIDI 28	Chorus Rate
		MIDI 29	"ChorusDelay I/O (sys), InEQ: Treb boost"
174	Cymbal Singers	MWheel	Vibrato
		Data	Layer 3 volume (ride cymbal)
		MIDI 22	"BandPass Width, HiPass Res"
		MIDI 23	Pan LFO adj
		MIDI 24	InEQ: Treb cut
		MIDI 25	(Aux) LaserVrb Level
		MIDI 26	LaserVrb contour
		MIDI 27	Pitch LFO Rate
		MIDI 28	Flange FB
		MIDI 29	Toggle: Pitcher + PitcherFlange
175	BriteBells^Glock	MWheel	Vibrato
		Data	Layer Toggle: BriteBells + Glock
		MIDI 22	Layer Levels ^ EnvCtl: Att
		MIDI 23	"Pitch adj, EnvCtl: Dec"
		MIDI 24	InEQ: Bass ^ EnvCtl: Imp
		MIDI 25	"(Aux) Room Level, (FX1) Hall Wet/Dry cut"
		MIDI 26	Room Decay Time
		MIDI 27	"Chorus Wet/Dry, Echo Wet/Dry"
		MIDI 28	"Chorus FB, Echo FB"
		MIDI 29	"Toggle: Chorus in/out, Hall + Echo out"
176	Crystalline^RX7	MWheel	"Shaper ctl, Vibrato ^ Pan adj"
		Data	Toggle: Crystalline ^ RX7
		MIDI 22	"ShapeMod osc Pitch, Shape amt ^ LoPass Freq, Pitch adj"
		MIDI 23	"LoPass Res, EnvCtl: Att"
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Room Level
		MIDI 26	Room Decay Time+HFDamp
		MIDI 27	"Chorus Wet/Dry, Echo Wet/Dry"
		MIDI 28	"Chorus FB, Echo FB"
		MIDI 29	Toggle: Chorus + Echo
177	Wave Power 2	MWheel	"Vibrato, In Pan adj"
		Data	"Layer enable, EnvCtl: Dec+Rel"
		MIDI 22	"Hall Wet/Dry, Layer Delay"
		MIDI 23	Hall Time
		MIDI 24	LaserVrb contour
		MIDI 25	"InEQ: Bass, Laser spacing"
		MIDI 26	"InEQ: Treb, Laser envelope"
		MIDI 27	Laser Level+FB+Pitch
		MIDI 28	LaserDelay Time
		MIDI 29	Pitcher Level
178	Trinibell	MWheel	Pitch ASR ctl
		Data	Hi+LoPass Freq
		MIDI 22	"Hi+LoPass Freq+Res, Pitch LFO"
		MIDI 23	"Enc Ctl - Att, Dist Drive adj"
		MIDI 24	EnvCtl: Rel
		MIDI 25	Tremolo Depth
		MIDI 26	Flange Wet/Dry
		MIDI 27	Chorus Mix
		MIDI 28	Delay FB (sys)
		MIDI 29	Flange FB boost
179	Dist Drive	MWheel	"Dist Drive, Hi+LoPass Freq"
		Data	Layer 3 volume (ride cymbal)
		MIDI 22	"BandPass Width, HiPass Res"
		MIDI 23	Pan LFO adj
		MIDI 24	InEQ: Treb cut
		MIDI 25	(Aux) LaserVrb Level
		MIDI 26	LaserVrb contour
		MIDI 27	Pitch LFO Rate
		MIDI 28	Flange FB
		MIDI 29	Toggle: Pitcher + PitcherFlange

ID	Name		
174	Cymbal Singers	MWheel	Vibrato
		Data	Layer 3 volume (ride cymbal)
		MIDI 22	"BandPass Width, HiPass Res"
		MIDI 23	Pan LFO adj
		MIDI 24	InEQ: Treb cut
		MIDI 25	(Aux) LaserVrb Level
		MIDI 26	LaserVrb contour
		MIDI 27	Pitch LFO Rate
		MIDI 28	Flange FB
		MIDI 29	Toggle: Pitcher + PitcherFlange
175	BriteBells^Glock	MWheel	Vibrato
		Data	Layer Toggle: BriteBells + Glock
		MIDI 22	Layer Levels ^ EnvCtl: Att
		MIDI 23	"Pitch adj, EnvCtl: Dec"
		MIDI 24	InEQ: Bass ^ EnvCtl: Imp
		MIDI 25	"(Aux) Room Level, (FX1) Hall Wet/Dry cut"
		MIDI 26	Room Decay Time
		MIDI 27	"Chorus Wet/Dry, Echo Wet/Dry"
		MIDI 28	"Chorus FB, Echo FB"
		MIDI 29	"Toggle: Chorus in/out, Hall + Echo out"
176	Crystalline^RX7	MWheel	"Shaper ctl, Vibrato ^ Pan adj"
		Data	Toggle: Crystalline ^ RX7
		MIDI 22	"ShapeMod osc Pitch, Shape amt ^ LoPass Freq, Pitch adj"
		MIDI 23	"LoPass Res, EnvCtl: Att"
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Room Level
		MIDI 26	Room Decay Time+HFDamp
		MIDI 27	"Chorus Wet/Dry, Echo Wet/Dry"
		MIDI 28	"Chorus FB, Echo FB"
		MIDI 29	Toggle: Chorus + Echo
177	Wave Power 2	MWheel	"Vibrato, In Pan adj"
		Data	"Layer enable, EnvCtl: Dec+Rel"
		MIDI 22	"Hall Wet/Dry, Layer Delay"
		MIDI 23	Hall Time
		MIDI 24	LaserVrb contour
		MIDI 25	"InEQ: Bass, Laser spacing"
		MIDI 26	"InEQ: Treb, Laser envelope"
		MIDI 27	Laser Level+FB+Pitch
		MIDI 28	LaserDelay Time
		MIDI 29	Pitcher Level
178	Trinibell	MWheel	Pitch ASR ctl
		Data	Hi+LoPass Freq
		MIDI 22	"Hi+LoPass Freq+Res, Pitch LFO"
		MIDI 23	"Enc Ctl - Att, Dist Drive adj"
		MIDI 24	EnvCtl: Rel
		MIDI 25	Tremolo Depth
		MIDI 26	Flange Wet/Dry
		MIDI 27	Chorus Mix
		MIDI 28	Delay FB (sys)
		MIDI 29	Flange FB boost
179	Dist Drive	MWheel	"Dist Drive, Hi+LoPass Freq"
		Data	Layer 3 volume (ride cymbal)
		MIDI 22	"BandPass Width, HiPass Res"
		MIDI 23	Pan LFO adj
		MIDI 24	InEQ: Treb cut
		MIDI 25	(Aux) LaserVrb Level
		MIDI 26	LaserVrb contour
		MIDI 27	Pitch LFO Rate
		MIDI 28	Flange FB
		MIDI 29	Toggle: Pitcher + PitcherFlange

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
179	Frozen^ Pizzibell	MWheel	Tremolo
		Data	Toggle: Frozen ^ Pizzibell
		MIDI 22	Hi+LoPass Freq ^ EnvCtl: Imp
		MIDI 23	"LoPass Res, Env Ctl - Att"
		MIDI 24	"LoPass Freq+Res, HiPass Freq ^ EnvCtl: Rel"
		MIDI 25	Delay Mix (sys)
		MIDI 26	Delay Time
		MIDI 27	Chorus Mix
		MIDI 28	"(Aux) Wet/Dry cut, InEQ: Bass"
		MIDI 29	Toggle: Flange I/O
180	Dencity	MWheel	Pitch LFO adj
		Data	"LoPass Freq, ChorDelay Wet/Dry"
		MIDI 22	LoPass LFO
		MIDI 23	"Pan ctl, EnvCtl: Att"
		MIDI 24	"Pitch ctl, EnvCtl: Rel"
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Time
		MIDI 27	Delay Time (sys)
		MIDI 28	Delay Mix + FB
		MIDI 29	"Toggle: Chorus I/O, Delay Level"
181	Synth Bell 1^2	MWheel	"Vibrato, Pan adj, LoPass Res"
		Data	"Toggle: Synth Bells 1 + 2, AltCtl adj"
		MIDI 22	"LoPass Res, BandPass Width, EnvCtl: Rel"
		MIDI 23	Pan adj
		MIDI 24	Pitch LFO adj
		MIDI 25	"(Aux) Hall Level, (fx1) Chapel Wet/Dry"
		MIDI 26	"Hall HFDamp+Time, Chapel Time"
		MIDI 27	"Chapel preDelay, SRS center Freq adj"
		MIDI 28	"Chapel EarlyRef+Late Levels, SRS EQ adj"
		MIDI 29	Toggle: Chapel + SRS
182	DynPercMix^Gator	BKeyNu	EnvCtl: Att+Dec+Rel
		MPress	Vibrato
		MWheel	"LoPass Freq+Res, Layer EnvCtl: Rel+Att"
		Data	Toggle: DynPercMix + Gator
		MIDI 22	"Filt Freq+Res+Width, Pitch, EQ, EnvCtl: Att ^ Lo+AllPass Freq"
		MIDI 23	"LoPass Freq, Pitch adj ^ ParaMid+Treb Freq"
		MIDI 24	"BandPass Width, Layer Level + Xfade"
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall HFDamp + Decay Time
		MIDI 27	"Flange Wet/Dry, MDelay Wet/Dry"
183	Workingman Space	MIDI 28	"Flange FB, MDelay FB"
		MIDI 29	Toggle: Flange + TubeAmpDelayChorus
		ChanS	EnvCtl: Rel
		AttVel	EnvCtl: Dec

ID	Name		
183	Workingman Space	MWheel	slight Vibrato
		Data	"LoPass Freq, Pitch adj"
		MIDI 22	"HiPass Freq, HFstim, BandPass Width"
		MIDI 23	Pipe Pitch bend
		MIDI 24	Pipe Pitch adj
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Time
		MIDI 27	Hall HFDamp
		MIDI 28	Hall Wet/Dry cut
		MIDI 29	Toggle: ChorusVrb + St Image
184	OronicoKno^Shift	MPress	slight Vibrato
		MWheel	Vibrato
		Data	Toggle: OronicoKno + Shift
		MIDI 22	"HFstim adj, Pan adj"
		MIDI 23	"InEQ: Bass, Layer Xfade"
		MIDI 24	"InEQ: Treb, Pan adj, EnvCtl: Rel"
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Decay Time+PreDelay
		MIDI 27	Delay Mix (sys)
		MIDI 28	Chorus Delay Time
185	Ethereal Dawning	MIDI 29	Chorus Depth adj
		MPress	Vibrato
		AttVel	AltCtl
		MWheel	BandPass Freq+Width sweep
		Data	Layer enable
		MIDI 20	BandPass Width - Layer 1
		MIDI 22	BandPass Freq + Width - Layer 2
		MIDI 23	BandPass Width - Layer 3
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Level
186	RAVReligion^Prey	MIDI 26	Hall Decay Time
		MIDI 27	Flange Wet/Dry
		MIDI 28	Flange FB
		MIDI 29	"Toggle: Flange + CDR, InEQ: Bass"
		MPress	BandPass Freq
		MWheel	"Vibrato, Para EQ adj"
		Data	Toggle: RAVReligion + Prey
		MIDI 22	EnvCtl: Att ^ Shapemod Pitch
		MIDI 23	"InEQ: Bass, Shape amt, EnvCtl: Rel ^ LoPass Freq, EnvCtl: Dec+Rel"
		MIDI 24	"InEQ: Treb, LoPass Freq, EnvCtl: Rel + Dec"
188		MIDI 25	Toggle: (Aux) Hall + (fx1) Room cut
		MIDI 26	"Hall Decay Time, Room Time"
		MIDI 27	Phaser center Freq
		MIDI 28	Phaser FLFO Depth
		MIDI 29	Toggle: Room + Phaser
189		MPress	Vibrato

ID	Name		
187	Voyage	MWheel	"Vibrato, LoPass Freq"
		Data	Layer enable
		MIDI 22	"Pitch LFO Rate, LoPass Freq+Res, EnvCtl: Imp+Att+Rel"
		MIDI 23	EnvCtl: Dec
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Time+HFDamp
		MIDI 27	Chorus Mix
		MIDI 28	Chorus FB
		MIDI 29	"Chorus Rate, St Image L/R Delay"
		MPress	"Vibrato, LoPass Freq"
		MIDI 70	AltCtl
188	WispSingsr^Glass	MWheel	"Vibrato, LoPass Res"
		Data	Toggle: WispSingsr + Glass
		MIDI 22	"LoPass Freq+Res, HiPass Freq"
		MIDI 23	"LoPass Freq, HiPass Res+Freq, Layer Levels"
		MIDI 24	EnvCtl: Att+Rel
		MIDI 25	(Aux) Hall + (fx1) Hall Wet/Dry
		MIDI 26	Hall Times+HFDamp
		MIDI 27	Chorus Wet/Dry
		MIDI 28	Delay Wet/Dry (sys)
		MIDI 29	Toggle: Hall + CDR
		MPress	Vibrato
189	Luscious	MWheel	Vibrato
		Data	"Panner LFO Rate, Layer Delay, Layer Xfade"
		MIDI 22	EnvCtl: Imp+Att
		MIDI 23	"InEQ: Bass, EnvCtl: Dec"
		MIDI 24	"InEQ: Treb, EnvCtl: Rel"
		MIDI 25	(Aux) Hall Time+PreDelay+HFDamp
		MIDI 26	Flange Mix
		MIDI 27	Flange Rate
		MIDI 28	Flange FB
		MIDI 29	Hall PreDelay adj
		MPress	Vibrato
		Tempo	LoPass Freq
190	LightMist^Padify	MWheel	Vibrato
		Data	Toggle: LightMist + Padify
		MIDI 22	"Pitch adj, LoPass Freq"
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Level
		MIDI 26	Chorus Delay Time
		MIDI 27	Chorus Delay Depth
		MIDI 28	Delay Mix (sys)
		MIDI 29	Hall Time+PreDelay adj
		MPress	Vibrato
191	VortexRev^Launch	MWheel	Vibrato
		Data	Toggle: VortexRev + Launch
		MIDI 22	"HiPass Freqs+Width, EQ adj"
		MIDI 23	"InEQ: Bass, Layer Xfade"
		MIDI 24	"InEQ: Treb, EnvCtl: Att+Rel"
		MIDI 25	(Aux) Hall Time
		MIDI 26	Hall PreDelay
		MIDI 27	Chorus Depth+Delay
		MIDI 28	Delay Mix+FB
		MIDI 29	Hall HFDamp
		MPress	Vibrato

ID	Name		
192	Hello^A No Way	MWheel	LoPass Freq
		Data	Toggle: Hello + A No Way
		MIDI 22	"LoPass Freq LFO, Pitch mod"
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Level+Time
		MIDI 26	Hall build+PreDelay
		MIDI 27	Chorus FB
		MIDI 28	Chorus Delay
		MIDI 29	Delay Mix
		MPress	Pitch mod
193	Environments	MWheel	""hi bird"" LFO Rate, Panner adj"
		Data	""lo bird"" LFO Rate"
		MIDI 22	"ParaEQ Freq, shaper amt"
		MIDI 23	"Pitch adj, LoPass Freq, BandPass Freq+Width"
		MIDI 24	"HiPass Freq, Pitch (sine)"
		MIDI 25	"Chorus Level, rvb Level, CDR Wet/Dry"
		MIDI 26	(fx2) Chorus Wet/Dry
		MIDI 27	Phaser Wet/Dry
		MIDI 28	CDR Wet/Dry
		MIDI 29	Chorus Rate
		MPress	InEQ: Bass
		MIDI 70	AltCtl
194	Gremlin Groupies	MWheel	"Layer Pitch, LoPass Freq+Res, Wrap adj"
		Data	"Layer Pitch, LoPass LFO adj"
		MIDI 22	"Layer Pitch, Pitch (Sine) adj"
		MIDI 23	Layer Pitch adj
		MIDI 24	"Layer Pitch, Wrap adj"
		MIDI 25	(Aux) Hall Level
		MIDI 26	"Pitcher Wet/Dry, LsrDelay Time+Wet/Dry"
		MIDI 27	"Pitcher wts pair, Lsr Spacing"
		MIDI 28	"Pitcher wts odd, Lsr Contour"
		MIDI 29	Toggle: Pitcher + LaserDelay
195	Lost In Space	MWheel	"LoPass Freq adj, Pitch adj"
		Data	HiPass Freq adj
		MIDI 22	LoPass + HiPass Freq adj
		MIDI 23	"Layer Pitch, EnvCtl- atk"
		MIDI 24	EnvCtl- Rel
		MIDI 25	Delay Mix
		MIDI 26	Delay Time
		MIDI 27	Ch FB
		MIDI 28	Ch Depth
		MIDI 29	Toggle: (Aux) Plate I/O
		MPress	
196	Lunar Wind	MWheel	LoPass Freq+Res
		Data	Pitch adj
		MIDI 22	"LoPass Res, Pan adj"
		MIDI 23	Panner sweep
		MIDI 25	(Aux) Room Level
		MIDI 26	Pitcher Wet/Dry
		MIDI 27	Flange Mix (sys)
		MIDI 28	Pitcher Pitch
		MIDI 29	Toggle: Pitcher I/O
		MPress	"LoPass Freq, Pan LFO"
		ChanS	EnvCtl: Rel
		Breath	LoPass adj

Standard K2600 ROM Objects

Program Control Assignments

ID	Name			ID	Name		
197	Noise Toys	MWheel	"Pitch LFO, Shaper amt"	780	Ballad Piano	MWheel	Tremolo
		Data	"Pitch (Sine+) adj, BandPass Freq, Dist amt"			Data	Layer Enable/Disable
		MIDI 22	"Pitch adj, Shaper LFO, HiPass Freq"			MIDI 23	InEQ: Bass
		MIDI 23	"LoPass + HiPass Freq, EnvCtl: Att"			MIDI 24	InEQ: Treb
		MIDI 24	EnvCtl: Rel			MIDI 25	(Aux) Hall Level
		MIDI 25	(Aux) Hall Level			MIDI 26	(Aux) Hall Time
		MIDI 26	"LrsDelay Wet/Dry, Pitch Wet/Dry"			MIDI 29	Soundboard I/O
		MIDI 27	"LsrDelay contour, Pitch pair weights"	781	Piano&SpaceyPad	MWheel	Pad Balance
		MIDI 28	Pitch odd weights			MIDI 22	Notch Filt Freq+Width
		MIDI 29	Toggle: Laser + Pitch			MIDI 23	Panner
		MPress	"Vibrato, Pitch LFO adj"			MIDI 24	EnvCtl: Release (Pad)
		PWheel	Shaper adj			MIDI 25	(Aux) Hall Level
		Tempo	LsrDelay Delay coarse + spacing			MIDI 26	(Aux) Hall Time
770	Concert Piano 2	MIDI 25	(Aux) Hall Level+Time	782	Lush Piano Pad	MWheel	"Vibrato, Pan adj"
771	Studio Grand	MIDI 25	(Aux) Hall Level+Time			Data	"Layer Enable, Delay "
		MIDI 29	Soundboard Rvb Enable			MIDI 22	"EnvCtl: Att+Dec, Rel (Layers1+2)"
772	Soft Piano		(Soft Pedal is Active)			MIDI 23	"EnvCtl: Dec (Layers 3+4), InEQ: Bass"
		MIDI 25	(Aux) Hall Level+Time			MIDI 24	"EnvCtl: Rel (Layers 3+4), InEQ: Treb"
773	MonoStudioGrand	Sustain	Soundboard Wet/Dry Increase			MIDI 25	(Aux) Hall Wet/Dry+PreDelay+HFDamp
		Data	ParaTreb Gain			MIDI 26	Flange Mix
		MIDI 25	(Aux) Hall Level+Time			MIDI 27	Flange Rate+Xcurs
774	RandomPan Grand		(Soft Pedal is Active)			MIDI 28	Flange FB
		MIDI 25	(Aux) Hall Level+Time			MPress	"Vibrato, Layer Balance"
775	Funky Piano	MWheel	ParaEQ LFO Depth	783	Rotating Piano	MWheel	Leslie Enable
		MIDI 23	InEQ: Bass			MIDI 25	(Aux) Plate Level
		MIDI 24	InEQ: Treb			MIDI 26	Plate Time
		MIDI 25	(Aux) Room Level+Time			MIDI 27	Hi/Low Tremolo adj
		MIDI 26	Flange Wet/Dry			MIDI 28	(Aux) HFDamp
		MIDI 27	Flange FB			MIDI 29	Toggle: VibratoChorus I/O
		MIDI 28	Flange XCouple	784	MajesticPianoism	Soft Ped	Leslie Enable
		MIDI 29	Flange LFO Tempo			MWheel	Vibrato/Tremolo
		MPress	ParaEQ Depth			Data	Disable Strings
776	Piano Chase	MWheel	Vibrato (Strings)			MIDI 22	LoPass Freq+Res (Strings)
		MIDI 23	InEQ: Bass			MIDI 25	(Aux) Hall Level
		MIDI 24	InEQ: Treb			MIDI 26	(Aux) Rvb Time
		MIDI 25	(Aux) Plate Level+Time			MIDI 27	(insert) Room Wet/Dry
		MIDI 26	Flange Wet/Dry			AttVel	Enables Dull Saw Wave
		MIDI 27	"Flange FB, (Aux) Decay Time"	785	Sonar Piano	MWheel	Vibrato (clave)
		MIDI 28	Flange LFO Tempo			MIDI 25	(Aux) Hall Level
		MIDI 29	Flange XCouple			PWheel	Octave Shift
		MPress	Vibrato (Strings)	786	Pop Grand	Data	Enhc Low Mix
777	Grand+Elec 1	Sost Ped	Disables Strings			MIDI 22	Enhc Mid Mix
		MWheel	Layer Balance			MIDI 23	Enhc Hi Mix
778	Grand+Elec 2	MIDI 25	"(Aux) Hall Level, Room Wet/Dry"			MIDI 25	(Aux) FDR Level
		MWheel	E Pno Vibrato + ParaTreb			MIDI 26	Flange Wet/Dry
		MIDI 23	InEQ: Bass			MIDI 27	Flange Tempo
		MIDI 24	InEQ: Treb			MIDI 29	(Aux) Delay Mix
		MIDI 25	(Aux) Hall Level	787	Grandsichord	MWheel	Vibrato
		MIDI 26	Chorus Wet/Dry			Data	"Slight detune, EnvCtl: Att+Rel"
		MIDI 27	Chorus FB			MIDI 22	Hi Freq Stimulator Cut
		MIDI 28	Chorus XCouple			MIDI 25	(Aux) FDR Level
		MIDI 29	(Aux) Early Ref Level			MIDI 26	Flange Wet/Dry
		Soft Ped	Softens Elec Piano			MIDI 27	Flange Tempo
		MWheel	"Vibrato, Tremolo"			MIDI 28	Enhc Lo/Mid Drive
779	Detuned Piano	Data	Detune			MIDI 29	(Aux) Delay Mix
		MIDI 25	(Aux) Hall Level				
		MIDI 26	(Aux) Hall Time				
		MIDI 27	Room Wet/Dry				